




CONTROL PANEL




PAUSE OR STOP COOKING

TO PAUSE COOKING:


THE COOKING CAN BE PAUSED to check, turn or stir the food by opening the door. The setting will be maintained for 5 minutes.

TO CONTINUE COOKING:


CLOSE THE DOOR and press the Jet Start button  ONCE. The cooking is resumed from where it was paused.

PRESSING THE START BUTTON TWICE will increase the time by 30 seconds.

IF YOU DON'T WANT TO CONTINUE COOKING:

REMOVE THE FOOD, close the door and press the STOP button .

NOTE: After cooking ends, the fan and cavity lamp is on before pressing STOP button, it's normal.

A BEEP WILL SIGNAL once a minute for 5 minutes when the cooking is finished. Press the STOP button  or open the door to cancel the signal.

NOTE: The oven will only hold the settings for 60 seconds if the door is opened and then closed after the cooking is finished.

CHILD LOCK/TOUCH LOCK

THIS AUTOMATIC SAFETY FUNCTION IS ACTIVATED 2 MINUTES AFTER the oven has returned to "stand by mode". In this mode the door and touch button are locked.



THE DOOR MUST BE OPENED AND CLOSED e.g. putting food into it, before the safety lock is released. Else the display will show "door".

JET START

THIS FUNCTION IS USED for quick reheating of food with a high water content such as clear soups, coffee or tea.

- 1 **PRESS THE JET START BUTTON.**

THIS FUNCTION AUTOMATICALLY STARTS with maximum microwave power level and the cooking time set to 30 seconds. Each additional press increases the time with 30 seconds. You may also alter the time by pressing +/- button to increase or decrease the time after the function has started.

COOK & REHEAT WITH MICROWAVES

USE THIS FUNCTION for normal cooking and reheating, such as vegetables, fish, potatoes and meat.

- 1 **PRESS THE POWER BUTTON** repeatedly to set the power.
- 2 **PRESS +/- BUTTON** to set the cooking time.
- 3 **PRESS THE JET START BUTTON.**

ONCE THE COOKING PROCESS HAS BEEN STARTED:

The time can easily be increased in 30-second steps by pressing the Start button. *Each press* increases the time with 30 seconds. You may also alter the time by pressing +/- button to increase or decrease the time.

MICROWAVES ONLY	
POWER	SUGGESTED USE:
JET (700 W)	REHEATING OF BEVERAGES , water, clear soups, coffee, tea or other food with a high water content. If the food contains egg or cream choose a lower power.
500 W	MORE CAREFUL COOKING e.g. high protein sauces, cheese and egg dishes and to finish cooking casseroles.
350 W	SIMMERING STEWS , melting butter.
160 W	DEFROSTING . Softening butter, cheeses.





JET DEFROST

USE THIS FUNCTION for defrosting Meat, Poultry and Fish. JET Defrost should only be used if the net weight is between 100 g- 1.5 kg.

ALWAYS PLACE THE FOOD on the glass turntable.

- 1 **PRESS THE JET DEFROST BUTTON.**
- 2 **PRESS +/- BUTTON** to set the weight of the food.
- 3 **PRESS THE JET START BUTTON.**

MIDWAY THROUGH THE DEFROSTING PROCESS the oven stops and prompts you to *TURN FOOD*.

❧ Open the door.

❧ Turn the food.

❧ Close the door and restart by pressing the Start button.

*Turn
Food*


NOTE: The oven continues automatically after 2 min. if the food hasn't been turned. The defrosting time will be longer in this case.

FROZEN FOODS:

IF THE WEIGHT IS LESSER OR GREATER THAN RECOMMENDED WEIGHT: Follow the procedure for "Cook & Reheat with microwaves" and choose 160 W when defrosting.

IF THE FOOD IS WARMER than deep-freeze temperature (-18°C), choose lower weight of the food.

IF THE FOOD IS COLDER than deep-freeze temperature (-18°C), choose higher weight of the food.



KITCHEN TIMER

USE THIS FUNCTION when you need a kitchen timer to measure exact time for various purposes such as cooking eggs or letting the dough rise before baking etc.

- 1 **PRESS THE CLOCK BUTTON.**
- 2 **PRESS +/- BUTTON** TO SET THE TIME to measure.
- 3 **PRESS THE JET START BUTTON.**

FLASHING COLONS indicate that the timer is running.

AN ACOUSTIC SIGNAL will be heard when the timer has finished to count down.

ONE PRESS ON THE CLOCK BUTTON displays how much is left on the Timer. It's displayed for 3 seconds and then returns to displaying the cooking time (if you are currently cooking).

TO STOP THE KITCHEN TIMER when it is operating in the background of another function, you must first recall it to the foreground by pressing the Clock button and then stop it by pressing the Stop button.

CLOCK

- 1 **PRESS THE CLOCK BUTTON** (3 seconds) until the left-hand digit (hours) flicker.
- 2 **PRESS +/- BUTTON** to set the hours.
- 3 **PRESS THE CLOCK BUTTON AGAIN.** (The two right hand digits (minutes) flicker).
- 4 **PRESS +/- BUTTON** to set the minutes.
- 5 **PRESS THE CLOCK BUTTON AGAIN.**

THE CLOCK IS SET and in operation.

IF YOU WISH TO REMOVE THE CLOCK from the display once it has been set, simply press the Clock button again for 3 seconds and then press the Stop button.

TO REINSTATE THE CLOCK, follow the above procedure.

NOTE: KEEP THE DOOR OPEN WHILE SETTING THE CLOCK. This gives you 5 minutes to complete the setting of the Clock. Otherwise, each step must be accomplished within 60 seconds.

MEMORY

THE MEMORY FUNCTION PROVIDES you with an easy way to quickly recall a preferred setting.

THE PRINCIPLE OF THE MEMORY FUNCTION is to store whatever setting that is currently displayed.

HOW TO USE A STORED SETTING:

- 1 **PRESS THE MEMO BUTTON.**
- 2 **PRESS THE JET START BUTTON.**

HOW TO STORE A SETTING:

- 1 **SELECT** any function.
- 2 **PROGRAM** your settings.
- 3 **PRESS AND KEEP THE MEMO BUTTON PRESSED** for 3 seconds until an acoustic signal is heard. The setting is now stored. You may reprogram the memory as many times as you wish.

WHEN THE APPLIANCE is plugged in or after a power failure, your Memo function will have stored 1 minute at full microwave power as default setting.

MANUAL DEFROST

- 1 **PRESS THE MANUAL DEFROST BUTTON.**
- 2 **PRESS +/- BUTTON** to set the cooking time.
- 3 **PRESS THE JET START BUTTON.**

FROZEN FOOD IN PLASTIC BAGS, plastic films or cardboard packages can be placed directly in the oven as long as the package has no metal parts (e.g. metal twist ties).

THE SHAPE OF THE PACKAGE alters the defrosting time. Shallow packets defrost more quickly than a deep block.

SEPARATE PIECES as they begin to defrost. Individual slices defrost more easily.

SHIELD AREAS OF FOOD with small pieces of aluminum foil if they start to become warm (e.g. chicken legs and wing tips).



IN THIS MODE the MW power level can not be adjusted, and it will be fixed to 160w.

CHECK AND INSPECT THE FOOD REGULARLY. Experience will give you the times needed for various amounts.

TURN LARGE JOINTS halfway through the defrosting process.

BOILED FOOD, STEWS AND MEAT SAUCES defrost better if stirred during defrosting time.

WHEN DEFROSTING it is better to under-thaw the food slightly and allow the process to finish during standing time.

STANDING TIME AFTER DEFROSTING ALWAYS IMPROVES the result since the temperature will then be evenly distributed throughout the food.



TECHNICAL SPECIFICATION

SUPPLY VOLTAGE	230 V/50 Hz
RATED POWER INPUT	1100 W
FUSE	10 A (UK 13 A)
MW OUTPUT POWER	700 W
OUTER DIMENSIONS (HxWxD)	360 x 392 x 350
INNER DIMENSIONS (HxWxD)	149 x 290 x 290



4 6 1 9 6 6 2 0 4 2 0 1

