



Register your new Bosch now:
www.bosch-home.com/welcome



Tumble dryer
WTW85530BY

BOSCH

en Installation and operating instructions

Your new tumble dryer

You have opted for a tumble dryer manufactured by Bosch.

Please take a few minutes to read and become familiar with the advantages of your tumble dryer.

To meet the high quality demands required by Bosch, every tumble dryer that leaves our factory is carefully checked to ensure that it functions correctly and is in perfect condition.

For more information on our products, accessories, replacement parts and services, see our website www.bosch-home.com or contact our Customer Service centres.

If the operating and installation instructions describe different models, any differences will be pointed out at the relevant points in the text.



Read these operating and installation instructions before operating the tumble dryer.

Display rules

⚠ Warning!

This combination of symbol and signal word indicates a possibly dangerous situation. Not heeding the warning can cause death or injuries.

Caution!

This signal word indicates a possibly dangerous situation. Not heeding the caution can cause property and/or environmental damage.

Note/tip

Information about the optimum use of the appliance/any other useful information.

1. 2. 3. / **a) b) c)**

The steps are represented by numbers or letters.

■ / -

Lists are represented by a small box or a dash.

Contents


Intended use 4


Safety instructions 4

Electrical safety 4
Safety for children 5
Appliance safety 5


Environmental protection 7

Packaging/old appliance 7
Coolant 7
Energy-saving tips 7


The main points in brief 8


Getting to know your appliance . 9

Dryer 9
Control panel 10
Display panel 11


Laundry 12

Preparing the laundry 12
Sorting washing according to: 12


Programmes and buttons 13

Programmes 13
Buttons 15


Operating the appliance 16

Loading laundry and switching on the dryer 16
Setting a programme 16
Filling the refresher tank 17
Starting the programme 17
Programme sequence 17
Changing the programme or adding laundry 17
Cancelling the programme 18
Programme end 18
Removing laundry and switching off the dryer 18
Clean the fluff filter 18
Emptying the condensate container 20


Signal setting 21


Noises 22


Cleaning 23

Cleaning the dryer and the control panel 23
Cleaning the moisture sensor 23
Cleaning the filter in the condensate container 23
Cleaning the filter in the refresher tank 24
Cleaning the steam nozzle 24


Faults and what to do about them 25


After-sales service 27


Consumption values 28

Consumption values table 28
Most efficient programme for cotton fabrics 28


Technical data 29


Installation and connection . . . 30

Scope of delivery 30
Installing and connecting the dryer . . 30
Optional accessories 31
Transport and frost protection 27

Intended use

The dryer should:

- Not be operated in outdoor areas,
- Be operated for domestic use only and
- Only be used for drying and refreshing fabrics that are labelled as suitable for tumble-drying on the care label.
- The dryer can be operated by children 8 years old and older, by persons with reduced physical, sensory or mental abilities and by persons with insufficient experience or knowledge if they are **supervised** or have been **instructed** in its use by a responsible adult.
- Keep children under three years of age away from the dryer.
- Do not allow children to clean or carry out maintenance work on the dryer unsupervised.
- Keep pets away from the dryer.

Safety instructions

Electrical safety

⚠ Warning
Risk of death!

There is a risk of electric shock as the dryer is operated with electricity.
You should therefore observe the following:

- Never touch or hold the mains plug with wet hands.
- Only pull out the mains cable directly at the plug and never by the cable, as this could damage it.
- Do not use extension cables, multiple plugs or connectors.
- Only have the mains cable replaced by our after-sales service.

Safety for children

⚠ Warning
Risk of death or injury!
You should therefore observe the following:

- Do not leave the dryer unattended when children or other people who cannot assess the risks are nearby.
- Do not let children play with the dryer.
- Children may become entangled in packaging or film if allowed to play with them, or they may pull them over their heads and suffocate. Keep packaging, packaging parts and film out of the reach of children.
- Children may lock themselves in the dryer. Therefore, when an appliance has reached the end of its service life, unplug it from the mains, cut through the mains cable and destroy the lock on the dryer door.

Appliance safety

⚠ Warning
Danger of death!

- Do not use the dryer if industrial chemicals have been used to clean it.
- Laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite or cause an explosion when drying is in progress. Before drying, wash the laundry in hot water with detergent.
- Coal dust or flour in the area around the dryer may cause an explosion.
- Only replace defective components with genuine spare parts.

Caution!
Risk of material damage to the dryer or fabrics.

- Only use the dryer for drying and freshening up fabrics at home and for fabrics that have been washed with water and are suitable for tumble-drying.
  Any other use is not considered intended use and is prohibited.
- Foamed material or foam rubber may become deformed or melt during drying. Do not dry any laundry that contains foamed material or foam rubber.
- Do not lean or sit on the dryer door, as the dryer may tip over.
- Loose cables or hoses may cause you to trip. Avoid tripping hazards.
- Light things, such as hair, may be sucked into the air inlet while drying is in progress; keep these away from the dryer.
- Heat is not added during the last part of the drying cycle (cooling cycle), to ensure that the laundry remains at a temperature that will not damage it.

Environmental protection

Packaging/old appliance

Dispose of packaging in an environmentally-responsible manner.

This appliance is designated according to European directive 2012/19/EC which governs waste electrical and electronic equipment (WEEE).

The directive provides a framework for the collection and recycling of old appliances, which is valid across the EU.

Coolant

The dryer's heat exchanger contains fluorinated greenhouse gas in a hermetically sealed unit.

Greenhouse gas:	R134a
Capacity (g):	220
GWP ($kgCO_2$/kgRefrig):	1300
Total GWP ($kgCO_2$):	286


Dispose of the dryer properly.

Energy-saving tips

- Spin the laundry before drying. The drier the laundry, the shorter the drying time will be, thus consuming less energy.
- Load the dryer with the maximum load.
  Note: Do not exceed the maximum load for the programs, as this prolongs the drying time and increases energy consumption.
- Ventilate the room and keep the air inlet on the dryer free to ensure air exchange.
- Clean the fluff filter after each drying cycle. If the fluff filter is dirty, the drying time is prolonged and energy consumption is increased.
- **Energy saving mode**: If the dryer is not operated for a prolonged period, it automatically switches off before the program starts and when the program has ended to save energy. The display panel and indicator lamps go off after a few minutes and the Start button flashes. To activate the lighting, press any button, open or close the dryer door or turn the program selector.

The main points in brief


1



Load the laundry and close the door.




Switch the dryer on.




Select a programme and, if necessary, adjust the programme default settings.

2



Select the start button ▷II.



Dry.




Remove the laundry.


3



Switch the dryer off.




Empty the condensate container.



Clean the fluff filter.

Getting to know your appliance

Dryer




1 condensate container
2 Control and display panel
3 Drum interior light*
4 Dryer door
5 Air inlet
6 Fluff filter

* Depending on the model

Control panel

Note: All buttons are sensitive and only need to be touched briefly.



1 **Programmes**.

2 **Programme selector** and **On/Off button**.


3 **Display panel** with **buttons** ⟶ *Page 13*.

4 **Start button** for starting, interrupting or cancelling the programme.

5 **Buttons**⟶ *Page 15*.

Display panel

Buttons on the display panel



1 Selects the **amount of steam** for the steam programmes.

2 Selects the **childproof lock**.

3 Selects **Anti-Crease**.

4 Selects **Anti-Crease**.

5 Selects **Low-Heat Drying**.


6 Switches the **audible signal** on or off.

7 Adjusts the **dryness level**.

8 The **degree of dryness** finely adjusts the dryness levels.

9 **- Ready in +** delays the start of the programme.

For a detailed description of all buttons, see ⟶ *Page 15* onwards.



Display panel

: Amount of steam.

: Dryness levels.

: Fine adjustment for the degree of dryness.

: Timed programme selected .

1:47: Expected programme duration in hours and minutes.

3 h: Programme delay in hours when "Ready in" time is selected.

: Empties the condensate container; .⟶ *Page 20*

: Cleans the fluff filter; .⟶ *Page 18*

: Fills the refresher tank; ⟶ *Page 17*.

: The heat exchanger is cleaned automatically.

- -: Programme progress: Dry; Iron Dry; Cupboard Dry; Anti-Crease; End and Pause.

Laundry

Preparing the laundry

Warning
Risk of explosion or fire!
Remove any cigarette lighters and matches from pockets.

Caution!
The dryer drum and fabrics may be damaged.

Remove all objects from pockets and take note of the following information:

- Tie cloth belts, apron strings, etc. together or use a laundry bag.
- Close zips, hooks and eyes, and do up any buttons.
- To ensure a consistent drying result, sort the laundry by fabric type and drying programme.
- Remove any metal objects, such as paper clips, from pockets.
- Knitted fabrics, such as T-shirts and jerseys, often shrink slightly the first time they are tumble-dried. Use a gentle programme.
- Do not over-dry easy-care laundry. This increases creasing of the laundry.
- When washing laundry that is to be tumble-dried afterwards, use the correct amount of fabric softener as specified in the manufacturer's instructions.

Sorting washing according to:

- Suitable for tumble drying
- Dry at normal temperature
- Dry at low temperature
- Do not tumble-dry

If you dry thin- or thick-layered fabrics or fabrics with several layers together, these will dry to differing degrees. To achieve an even drying result, you should therefore only dry laundry of the same type of fabric and structure together. If you feel that the laundry is still too damp afterwards, you can select a timed programme for subsequent drying ⟶ *Page 13*.

Caution!
Possibility of material damage to the dryer or laundry.

Do not dry non-breathable fabrics, such as rubber-coated laundry.

Programmes and buttons

Programmes

Programme and fabrics	Maximum load and programme settings/info
Name of the programme Which fabrics is the programme suitable for?	The maximum load is based on the dry weight of the fabrics Possible programme settings
Cottons Hard-wearing fabrics, heat-resistant fabrics made of cotton or linen	**9 kg**
Easy-Care Synthetic or blended fabrics	**3.5 kg**
Mix Mixed load consisting of cotton and synthetic fabrics	**3 kg**
Delicates For delicate, washable underwear, e.g. made of velvet, lace, Lycra, silk or satin.	**1 kg**
Wool finish Fabrics made from wool or a wool blend that are suitable for tumble drying	**3 kg**
Down Fabrics, pillows, bedspreads or eiderdowns filled with down. Dry large items individually.	**1.5 kg**
Sportswear Weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics	**1.5 kg**
Shirts/Business Non-iron shirts or blouses made of cotton, linen, synthetic fibres or blended fabrics	**3 kg**
Super 40' Synthetics and light cottons	**1 kg**

Timed program warm Timed programme for all types of fabric except for wool and silk. Dry laundry that is still slightly damp or has already been pre-dried. Also suitable for the subsequent drying of multi-layered, thick laundry that does not dry readily. **Note:** This programme is suitable for drying individual woollen fabrics, sports shoes and soft toys. Only dry these using the basket for woollens ⟶ *Page 31*.	**3 kg** You can alter the drying time using the button for the "Ready in" time.
Casual refresh Steam programme for casualwear made of cotton or synthetic fibres. Remove fabrics immediately after the programme has ended to prevent creasing.	**1.5 kg** Fabrics are refreshed, but not dried or washed. Fabrics must be suitable for tumble drying.
Business refresh Steam programme for suits, jackets, trousers or dry-clean items that cannot be washed in the washing machine. Remove fabrics immediately after the programme has ended to prevent creasing.	**1.5 kg** Fabrics are refreshed, but not dried or washed.
Easy-Care non-iron Steam programme for drying and smoothing out the creases in easy-care fabrics such as shirts/business shirts. Remove fabrics immediately after the programme has ended and hang them up to prevent creasing.	**1.5 kg** Best results can be achieved if "Non-iron" appears on the manufacturer's label. Select a larger amount of steam for thicker fabrics ⟶ *Page 15*.
Cottons non-iron Steam programme for drying and smoothing out the creases in hard-wearing fabrics such as bed linen, tablecloths or shirts/business shirts. Remove fabrics immediately after the programme has ended and hang them up to prevent creasing.	**2.5 kg** Best results can be achieved if "Non-iron" appears on the manufacturer's label. Select a larger amount of steam for thicker fabrics; see ⟶ *Page 15*.


Buttons

Buttons	Explanations and notes
Note: Not all buttons and their functions can be selected in all programmes.	
child lock push 3 sec	You can activate or deactivate the childproof lock by pressing and holding the childproof lock button for three seconds.
Easy-Iron 60 min	The drum moves the laundry at regular intervals after drying to prevent creasing. You can extend the automatic Anti-Crease function by 60 minutes after any programme has finished.
Easy-Iron 120 min	The drum moves the laundry at regular intervals after drying to prevent creasing. You can extend the automatic Anti-Crease function by 120 minutes after any programme has finished.
Low Heat	Reduced temperature for delicate fabrics, e.g. polyacrylic or elastane, may increase the drying time.
steam Adjust	Select the amount of steam for the steam programmes from (normal), (high) or (very high).
end signal	An audible signal sounds after the programme has ended.
Drying target:	Select the dryness level according to the laundry to be dried. If you have selected a dryness level, this is stored for all programmes, except for Cottons, even after the dryer has been switched off.
Cupboard Dry Plus	Multi-layered, thick laundry that does not dry readily.
Cupboard Dry	Normal, single-layered laundry.
Iron Dry	Normal, single-layered laundry that still needs to be damp after drying and is suitable for ironing or hanging up.
Fine adjust	If the laundry is too damp after drying, you can finely adjust the dryness levels e.g. Cupboard Dry. The dryness level can be increased with the degree of dryness in three stages, from to . If you have adjusted the dryness level, the setting for all programmes with a selectable dryness level is retained even after the dryer is switched off.
- Finished in +	The programme will end in between 1 h and 24 h. Set the "Ready in" time in increments of one hour to delay the start of the programme. The required number of hours after the programme ends is displayed on the display panel. The drying time for timed programmes can be set to between 10 minutes and 3 hours and 30 minutes, in 10-minute increments.
Start/Pause	Starts or pauses the programme.

Operating the appliance

Loading laundry and switching on the dryer

Note: The dryer must be correctly positioned and connected, ⟶ *Page 30*.



1. Place the laundry in the drum.
2. Press the ⏻ button to switch the dryer on.
3. Close the dryer door.

   Caution!

   Possibility of material damage to the dryer or laundry.


   Do not trap any laundry between the dryer door and the door seal.

Note: The dryer drum is lit up after the door is opened and closed and once the programme has started. The drum interior light goes out on its own.

Setting a programme

Note: If you have activated the childproof lock, you must deactivate it before you can set a programme, see ⟶ *Page 15*.

1. Select the required programme; detailed information on the programmes can be found on ⟶ *Page 13*.




2. Use the programme selector to set the required programme. The programme default settings for the selected programme appear in the display panel.

   Note: Programme default settings are standard settings that are already defined when a programme is selected. After selecting a programme, you can see the programme default settings in the display panel.
3. If required, adjust the programme default settings. You can find detailed information on this on ⟶ *Page 13*.

Filling the refresher tank

Note: If you select a steam programme, you must fill the refresher tank with distilled water.

1. Select the required steam programme from the Programmes section ⟶ *Page 13*.
2. Use the programme selector to set the required programme.
3. appears in the display panel.
   Note: If does not appear in the display panel, the refresher tank is already filled and does not need to be refilled. Press the Start button.
4. Pull out the condensate container.



5. Pour distilled water into the filling hole on the refresher tank using the jug provided until goes out on the display panel.
   Caution!
   The dryer may be contaminated with fluff or be damaged by deposits.
   Only fill the refresher tank with distilled water; do not use condensation or additives.
6. Push in the condensate container until you feel it lock into place.
7. Press the "Start" button.

Notes

- If you want to interrupt the programme (to add laundry, for example), open the dryer door and then press the Start button to continue.
- With the recommended load, the steam programmes use approx. 250 - 300 ml of distilled water.

Starting the programme

Press the Start button.

Note: If you want to lock the programme to prevent it from being inadvertently adjusted, you can select the childproof lock, see ⟶ *Page 15*.

Programme sequence

The programme status is displayed in the display field.

Changing the programme or adding laundry

Warning
Risk of scalding!
If you have selected a steam programme, hot steam may escape. You may scald yourself. Open the dryer door carefully.

You can remove or add laundry and change or alter the programme at any time during drying.

1. To pause the programme, open the dryer door or press the Start button.
2. Add or remove laundry.
3. Select another programme or an additional function, if required.
4. Close the dryer door.
5. Press the Start button.

Note: The programme duration in the display panel is updated depending on the load and residual moisture in the laundry. The values displayed may change after the programme is changed or the load is adapted.

Cancelling the programme

The programme can be interrupted at any time; to pause, open the dryer door or press the Start button.


Caution!
Risk of fire. Laundry may catch fire.
If you cancel the programme, you must remove the laundry items and spread them out so that the heat can disperse.

Programme end

- 0 - appears on the display panel.

Removing laundry and switching off the dryer

1. Remove the laundry.
2. Press the ⏻ button to switch the dryer off.




Clean the fluff filter


Note: During drying, fluff and hair from the laundry is trapped by the fluff filter. If the fluff filter is blocked or dirty, this reduces the flow of air, which prevents the dryer from achieving its maximum performance. Clean fluff filters also reduce energy consumption and the drying time.

Clean the fluff filter **after each** drying cycle:

1. Open the dryer door and remove all fluff from the door.
2. Pull out the two-part fluff filter.




3. Remove the fluff from the recess in the fluff filter.




Note: Ensure that no fluff falls into the open shaft.


4. Pull apart the two-part fluff filter.




5. Open both filters and remove all the fluff.



6. Rinse away the fluff under warm, running water.



7. Dry the fluff filter, close it and reinsert the two-part fluff filter.



Caution!
The dryer may be damaged.
Do not operate the dryer without a fluff filter or if the fluff filter is defective.

Emptying the condensate container


Notes

- You can drain the condensation using an optional condensation drain leading into the waste-water system.
- If you drain the condensation using an optional condensation drain, you do not need to empty the condensate container.


* Depending on the model

Note: After each drying cycle, empty the condensate container; otherwise the next drying programme may be cancelled as a result of the condensate container being full.

1. Pull out the condensate container horizontally.



2. Pour out the condensation water.



Caution!

Dirty condensation water may be harmful to your health and cause material damage.

Condensation water is not suitable for drinking and may be contaminated with fluff. Do not drink the condensation water or reuse it.

3. Push in the condensate container until you feel it lock back into place in the dryer.




Note: The filter in the condensate container filters the condensation which is used during the dryer's automatic cleaning cycle. The filter is cleaned by emptying the condensation. Nevertheless, you should check the filter regularly for remaining deposits and remove them. See ⟶ *Page 23*.

Signal setting

You can change the following settings:

- The volume of the audible signal at the end of the programme and/or
- The volume of the audible button signals.
- Activate or deactivate automatic switch-off.

You will need to activate the setting mode in order to change these settings.



Activating setting mode

1. Switch the dryer on.
2. Select the Cottons programme in position 1.
3. Press and hold the button for the degree of dryness and, at the same time, turn the programme selector clockwise to position 2.
4. Release the button for the degree of dryness.

The setting mode is now activated and the preset volume for the audible signal at the end of the programme appears on the display panel.

Changing the volume or automatic switch-off

Leave the programme selector or turn it to:

- Position 2: Press the button for the "Ready in" time to change the volume of the **audible signal at the end of the programme** and/or



1 = quiet,
2 = medium, 3 = loud,
4 = very loud

- Position 3: Press the button for the "Ready in" time to change the volume of the **audible button signals**.



0 = off, 1 = quiet,
2 = medium, 3 = loud,
4 = very loud

- Position 4: Press the button for the "Ready in" time to activate or deactivate **automatic switch-off** of the dryer. "ON" for activated and "OFF" for deactivated.

  Note: To save energy, your dryer will switch itself off after 15 minutes when the "Automatic switch-off" function is active.


Exiting setting mode

You can now end the process and switch off the dryer. The settings have been saved.


Noises

Note: During drying, the compressor and pump generate some noise which is entirely normal.


The compressor in the dryer may occasionally generate a humming noise. The volume of this noise varies depending on the programme and the progress of the drying.




The compressor is ventilated from time to time, which creates a whirring sound.



The automatic cleaning process causes a clicking noise.



The condensation is pumped into the condensate container using a pump. This generates pumping noises.



Cleaning

Cleaning the dryer and the control panel


Warning
Risk of death!
There is a risk of electric shock as the dryer is operated with electricity. Disconnect the dryer from the mains before cleaning.

Clean the dryer using only water and a soft, damp cloth.

Remove all detergent residue, spray residue or other residues immediately. Do not use cleaning agents or agents for pre-treating laundry (e.g. prewash sprays, stain removers). Do not use high-pressure cleaners or steam jet cleaners to clean your appliance.

Cleaning the moisture sensor

Note: The dryer is equipped with a stainless-steel moisture sensor. The moisture sensor measures how damp the laundry is.
After long periods of use, a fine layer of limescale can form on the moisture sensors. This must be removed regularly.




Open the door and clean the moisture sensor with a rough sponge.

Caution!
The moisture sensor may be damaged.
Do not clean the moisture sensor with steel wool and abrasive materials.


Cleaning the filter in the condensate container

Note: The filter in the condensate container cleans the condensation water that is used during the dryer's automatic cleaning cycle.


1. Pull out the condensate container horizontally.
2. Pour out the condensation water.
3. Remove the filter.



4. Clean the filter under warm, running water or in the dishwasher.



5. Push in the filter until you feel it lock into place.




Caution!
The dryer may be contaminated with fluff and thus become damaged.
Only operate the dryer with the filter inserted.

6. Push in the condensate container until you feel it lock into place.

Cleaning the filter in the refresher tank

Note: The filter in the refresher tank protects the refresher tank from being contaminated.

1. Pull out the condensate container horizontally.



2. Remove the filter and clean it under running water or in the dishwasher.
3. Reinsert the filter.

Caution!


The dryer may be damaged.

Only operate the dryer with the filter inserted.

4. Push in the condensate container until it locks into place.

Cleaning the steam nozzle

Note: The steam nozzle may be blocked by deposits such as limescale or fluff.



1. Open the door and remove the cover of the steam nozzle with a screwdriver.
2. Clean the cover under running water.
3. Push and lock the cover back in place.

Faults and what to do about them

Faults	Cause/remedy
on the display panel and drying has been interrupted.	■ Empty the condensate container and press the Start button. ■ If the optional condensation drain is installed, the drain hose may be blocked. Check the hose for deposits and flush the hose out.
on the display panel.	Clean the fluff filter and press the Start button.
SelfCleaning on the display panel.	Not a fault. The heat exchanger is cleaned automatically. Do not pull out the condensate container while this is displayed.
on the display panel.	■ Fill the refresher tank with distilled water and press the Start button.
Dryer does not start.	■ Mains plug plugged in or fuse checked? ■ Programme selected? Select a programme. ■ Dryer door open? Close the door. ■ Childproof lock activated? Deactivate the childproof lock. ■ "Ready in" time selected? Programme starts after a delay. ■ Steam programme selected and refresher tank empty? Fill the refresher tank.
Water overflows when filling the refresher tank.	■ The filter in the refresher tank may be blocked by deposits. Clean the filter ⟶ *Page 24*.
Creasing.	■ Creasing occurs when you have exceeded the maximum load or selected the wrong programme for the type of fabric. All the required information can be found in the programme table. ■ Remove clothes immediately after drying; creasing may occur if they are left in the drum.
Water is leaking out.	■ Not a fault; the dryer may be positioned on an incline. Level the dryer.
Laundry is not dried properly or is still too damp.	■ After the end of the programme, warm laundry feels damper than it actually is. Spread the laundry out and allow the heat to disperse. ■ Finely adjust the dryness level – this extends the drying time but does not increase the temperature. Your laundry will become drier ⟶ *Page 15*. ■ Select a programme with a longer drying time or increase the drying level. This does not increase the temperature. ■ Select a timed programme for subsequent drying of laundry that is still damp ⟶ *Page 13*. ■ If you have exceeded the maximum load for the programme, the laundry may not be dried properly. ■ Clean the moisture sensor in the drum. A fine layer of limescale may adversely affect the performance of the sensors and your washing will not dry properly ⟶ *Page 23*. ■ Drying has been interrupted as a result of a power cut, because the condensate container is full or because the maximum drying time has been exceeded. **Note:** See also the laundry tips ⟶ *Page 12*.

* depending on the model

Faults	Cause/remedy
Drying time too long?	■ The fluff filter may be dirty and cause drying to take longer. Clean the fluff filter. ■ If the air inlet on the dryer is blocked or not freely accessible, this may increase the drying time. Make sure that the air inlet remains unobstructed. ■ If the ambient temperature is higher than 35 °C, this may extend the drying time. ■ Insufficient air circulation in the room may increase the drying time. Ventilate the room.
Display panel goes off and Start button flashes.	Not a fault. Energy saving mode is active .
Residual water in the condensate container despite the dryer being connected to the condensation drain*.	Not a fault. If the condensation drain is installed, residual water remains in the condensate container due to the dryer's self-cleaning function.
Humidity in the room increases.	Not a fault. Make sure the room is sufficiently ventilated.
Power cut.	The drying programme is interrupted. Remove the laundry and spread it out, or restart the programme.
Unusual noises when drying.	Not a fault. Noises are produced by the automatic cleaning of the heat exchanger .
The dryer feels cold despite drying.	Not a fault. The dryer can dry efficiently at low temperatures using a heat pump.
* depending on the model	

Note: If you cannot rectify the fault yourself by turning the dryer off and on, please contact our after-sales service.

After-sales service

After-sales service

If you cannot rectify the fault yourself (see Faults and what to do about them), please contact our after-sales service. We will always find an appropriate solution in order to avoid unnecessary visits by engineers.

The contact details of your local after-sales service can be found in the enclosed after-sales service directory.

When contacting the after-sales service, please quote the dryer's product number (E no.) and production number (FD).

E-Nr. _____ FD _____

This information can be found on the inside of the dryer door and on the back of the dryer.

Trust the expertise of the manufacturer.

Contact us for assistance. In this way, you can rest assured that the repair will be carried out by trained service technicians using original spare parts.

Consumption values

Consumption values table

Programme	Spin speed which is used for spinning the laundry	Duration**		Energy consumption**	
Cottons		**9 kg**	**4.5 kg**	**9 kg**	**4.5 kg**
Cupboard Dry*	1400 rpm	204 min	126 min	1.91 kWh	1.06 kWh
	1000 rpm	226 min	131 min	2.12 kWh	1.20 kWh
	800 rpm	251 min	161 min	2.35 kWh	1.37 kWh
Iron Dry*	1400 rpm	138 min	83 min	1.36 kWh	0.84 kWh
	1000 rpm	164 min	99 min	1.62 kWh	0.98 kWh
	800 rpm	190 min	115 min	1.88 kWh	1.17 kWh
Easy-Care		**3.5 kg**		**3.5 kg**	
Cupboard Dry*	800 rpm	55 min		0.51 kWh	
	600 rpm	71 min		0.66 kWh	

For energy label evaluation, full and half treatment shall be testing alternately starting from half load.
* Programme setting for testing in accordance with the applicable EN 61121 standard.
** The values may differ from those specified, depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric and the amount of laundry being loaded.

Most efficient programme for cotton fabrics

The following "standard cottons programme" (identified with ⌓) is suitable for drying normal, wet cotton laundry and is most efficient in terms of its combined energy consumption for drying wet cotton laundry.

Standard programme for cottons in accordance with current EU regulation 932/2012			
Programme + Drying target	**Load**	**Energy consumption**	**Programme duration**
⌓ Cottons + Cupboard Dry	9 kg/4.5 kg	2.12 kWh/1.20 kWh	226 min/131 min
Programme setting for testing and energy labelling in accordance with Directive 2010/30/EU			

Technical data

Dimensions:

85 x 60 x 60 cm

Height x width x depth

Weight:

Approx. 57 kg

Maximum load:

9 kg

Condensate container:

4.6 l

Connection voltage:

220 - 240 V

Connected load:

Max. 1600 W

Fuse:

10 A

Drum interior light*

Ambient temperature:

5 - 35°C

Power consumption when switched off:

0.10 W

Power consumption when ready for use (left-on mode):

0.10 W

* depending on the model

Installation and connection

Scope of delivery

- Dryer
- Installation and operating instructions
- Basket for woollens*
- Condensation drain*

* Depending on the model

Installing and connecting the dryer

Warning
Risk of death!
There is a risk of electric shock as the dryer is operated with electricity.
- Check the dryer for visible damage. You must not operate the dryer if it is damaged.
- Before connecting the dryer to the power supply, ensure that the electric voltage specified on the rating plate matches the voltage of your socket.
- Only use earth-leakage circuit breakers with the following symbol: .
- Ensure that the mains cable is not kinked or trapped, and that it does not come into contact with heat sources or sharp edges.

Warning
Children may lock themselves in the dryer, putting their lives at risk!
Do not set up the dryer behind a door or sliding door, as this may obstruct the dryer door or prevent it from opening.

Caution!
Risk of injury
- Due to the heavy weight of the dryer, you may injure yourself if you lift it. Do not lift the dryer on your own.
- You could cut your hands on the sharp edges of the dryer. Do not hold the dryer by the sharp edges.
- Protruding parts on the dryer may break off when it is lifted or pushed. Do not move the dryer by holding onto protruding parts.

Caution!
Risk of material damage to the dryer or fabrics.
- Check the dryer for damage caused during transportation. Never operate a dryer if it is damaged.
- Any residual water in the dryer may freeze and damage the dryer. Do not install the dryer in rooms that are at risk of frost.

During installation, ensure that:
- The dryer is placed on a clean, level and firm surface,
- The mains plug can be accessed at all times,
- The air inlet on the dryer is kept clear and there is sufficient ventilation,
- The area around the dryer is kept clean and
- The dryer is levelled using the threaded feet. Use a spirit level to do this.

Optional accessories

Order optional accessories* from the after-sales service:

- **Washer/dryer stack connection set:**
  To save space, the dryer can be placed on top of a suitable washing machine of the same width and depth.
  The dryer must be fastened to the washing machine using this connection set.
  Order number, pull-out worktop included: **WTZ11400**;
  Order number, pull-out worktop not included: **WTZ20410**.
- **Platform:**
  For easier loading and unloading, raise your dryer with a platform.
  Transport laundry with the clothes basket integrated into the platform drawer.
  Order number: **WMZ20500**.
- **Basket for woollens:**
  Dry individual woollen items, sports shoes and soft toys in the basket for woollens.
  Order number: **WMZ20600**.

* depending on the model

Transport and frost protection

Empty the condensate container and residual water from the dryer:

1. Select any programme using the programme selector.
2. Press the Start button.
3. Wait for 5 minutes.
   Note: The condensation is drained.
4. Empty the condensate container again.
5. Switch off the dryer.

Caution!
Any residual water may leak out and cause material damage.

Transport the dryer in an upright position.

Caution!
The dryer contains coolant and may be damaged.

Allow the dryer to rest for two hours before initial use.

☏ **Advice and repair order in the event of faults**

GB 0344 892 8979 (Calls charged at local or mobile rate.)
IE 01450 2655 (0.03 € per minute at peak. Off peak 0.0088 € per minute.)

You can find the contact information for all countries in the attached after-sales service directory.

Robert Bosch, Hausgeräte GmbH
Carl-Wery-Straße 34
81739 München
DEUTSCHLAND

9001033967 (9409)