GK-701

MECHANICAL GAMING KEYBOARD

CHERRY MECHANICAL SWITCH

Micro-Star INT'L CO., LTD.
No.69, Lide St., Zhonghe Dist.,
New Taipei City 235, Taiwan(R.O.C.)
Tel:886-2-3234-5599
Fax:886-2-3234-5488
www.msi.com

Introduction

Thank you for choosing MSI GK-701 Mechanical GAMING keyboard. This keyboard will surely give you a delightful and professional experience in running PC games. This guide provides instructions and illustrations to help you get the most from the keyboard, and it is recommended to read this guide before using it.

Compatibility

- PC with built-in USB ports
- Operating System: Windows® XP/ Vista®/ 7/ 8/ 8.1

Hardware Installation

1.Connect the keyboard to the USB port.
2.The system will automatically install all the necessary drivers.

Compound Key Functions

- ***Multimedia Hotkeys (F5~F11, press with "Fn" key)***

Fn + F5	Fn + F6	Fn + F7	Fn + F8
Previous Track	Play/ Pause	Stop	Next Track

Fn + F9	Fn + F10	Fn + F11
Mute	Volume down	Volume Up

- ***Game Mode***

Fn + F12 — Press and hold the Fn key and then press the F12 key to disable or enable Windows Hotkey function.

- ***Keyboard Backlight Control***

MSI GK-701 provides 3 keyboard backlight modes and 4 selections of backlight LED brightness level.

Fn + F1 (mode)

Press and hold the Fn key and then press the F1 key to select 3 keyboard backlight modes recurrently
1.Keyboard backlight disabled.
2.Keyboard keys of W, A, S, D and arrow keys will be illuminated only.
3. Keyboard backlight enabled.

- ***Backlight LED Brightness Level***

Fn + F2 — Press and hold the Fn key and then press the F2 key to switch recurrently between 4 selections of backlight LED brightness level:
brightness level 1, brightness level 2, brightness level 3, and breathing mode.

介 紹

感謝選購由微星科技所推出的高品質電競鍵盤GK-701，於電競遊戲時使用本鍵盤將帶給使用者舒適及專業的體驗。
本手冊提供圖示與說明幫助使用者操作本鍵盤，建議使用者於使用本鍵盤之前，先行閱讀本手冊。

系 統 需 求

- 內建有USB 連接埠的個人電腦
- 作業系統：: Windows® XP/ Vista®/ 7/ 8/ 8.1

硬 體 安 裝

1.將鍵盤連接到個人電腦的 USB 連接埠
2.系統會自動偵測連接的硬體並安裝適當的驅動程式

功能鍵 (FN) 組合熱鍵

- **多媒體熱鍵 (F5~F11，與Fn鍵同時使用)**

Fn + F5	Fn + F6	Fn + F7	Fn + F8
前一首	播放/ 暫停	停止	下一首

Fn + F9	Fn + F10	Fn + F11
靜音	降低音量	提高音量

- **遊戲模式**

Fn + F12 — 按住 Fn 鍵不放，再按 F12 鍵，可以啟動或關閉 Windows 熱鍵功能。

- **鍵盤背光控制**

MSI GK-701提供 3 種鍵盤背光模式，以及四種背光LED燈亮度設定。

Fn + F1 (mode)

按住 Fn 鍵不放，再按 F1 鍵，可以循環選擇三種鍵盤背光模式
1.熄滅鍵盤背光
2.僅點亮鍵盤按鍵 W, A, S, D 以及方向鍵
3.點亮鍵盤背光

- **背光 LED 燈亮度設定**

Fn + F2 — 按住 Fn 鍵不放，再按 F2 鍵，可以循環選擇四種鍵盤背光 LED 燈亮度：亮度1、亮度2、亮度3，以及呼吸亮燈模式。