

## On-Screen Display

The monitor functions can be controlled with the On Screen Display.

Current setting will be saved and OSD will be turned off when the keys are not touched for a period of time (please see OSD section).

## Hot Key Operation

| Auto                                                                         | Exit               | ◀        | ▶      | Enter         | ⏻     |
|------------------------------------------------------------------------------|--------------------|----------|--------|---------------|-------|
| 1. Press 0-1 sec<br>→ auto adjustment<br>2. Press over 1 sec<br>→ input menu | I-style Video Mode | ECO Mode | Volume | OSD Main Menu | Power |

## Menu Operation

Pressing the ENTER button brings up the OSD main menu.

| Item                        | Content                                             |
|-----------------------------|-----------------------------------------------------|
| <b>Auto Adjust</b>          |                                                     |
| <b>Brightness/ Contrast</b> |                                                     |
| Brightness                  | Adjust the backlight brightness                     |
| Contrast                    | Adjust the contrast ratio                           |
| <b>Image adjust</b>         |                                                     |
| H. Position                 | adjust the horizontal position of display on screen |
| V. Position                 | adjust the vertical position of display on screen   |
| Clock                       | adjust the pixel clock                              |
| Phase                       | Adjust the phase                                    |

|                      |                                                                    |
|----------------------|--------------------------------------------------------------------|
| <b>Colour</b>        |                                                                    |
| 9300K                | Set color temperature to 9300 Kelvin                               |
| 7500K                | Set color temperature to 7500 Kelvin                               |
| 6500K                | Set color temperature to 6500 Kelvin                               |
| Custom colour        | Adjust color temperature to user defined value                     |
| <b>OSD Setup</b>     |                                                                    |
| H. Position          | Adjust OSD horizontal position                                     |
| V. Position          | Adjust OSD vertical position                                       |
| OSD timeout          | Adjust OSD timeout                                                 |
| H. Position          | Adjust OSD horizontal position                                     |
| V. Position          | Adjust OSD vertical position                                       |
| <b>Language</b>      |                                                                    |
| Language             | English, Français, Deutsch, Italiano, Polski, Español, Nederlands, |
| <b>Recall</b>        |                                                                    |
| <b>Miscellaneous</b> |                                                                    |
| Sharpness            |                                                                    |
| DDC/CI               | DDC/CI on/off                                                      |
| Information          | Information about input signal                                     |
| Adv. Contrast        | Advanced contrast                                                  |
| Display Mode         | Full screen/Keep aspect                                            |
| <b>Input Select</b>  |                                                                    |
| AUTO                 | Select automatic input detection                                   |
| Manual               | Select manual D-sub / DVI                                          |
| <b>Audio</b>         |                                                                    |
| Volume               | Adjust speaker volume                                              |
| Mute                 | Select mute on/off                                                 |