

Voyager Focus UC

User Guide

Contents

Overview	3
Headset	3
Charge stand*	4
USB Bluetooth adapter	4
Connect and pair	5
Connect to PC	5
Configure USB adapter	5
Pair to mobile device	5
Pair USB adapter again	6
Fit and charge	7
Wear on the right or left	7
Charge your headset	7
Check headset battery status	7
Load software	8
The basics	9
Make/Take/End Calls	9
Mute/unmute	10
Mute on reminder*	10
OpenMic	10
Volume	10
Play or pause music	10
Track selection	10
Use sensors	10
ANC	11
More Features	12
DeepSleep Mode	12
Answer calls from a second device	12
Change language	12
Update firmware	12
What's in the box	13
Accessories	13
Troubleshoot	14
Support	16

Overview


Headset



	Volume up/down
	Track backward*
	Play/pause music*
	Track forward*
ANC	Active noise cancelling
	Charge port
	Active call = mute/unmute Idle = OpenMic (hear your surroundings)
	Headset LEDs for pairing, battery status, online indicator
	Call button ([])
	Power button
	Bluetooth pair button

NOTE *Functionality varies by application. Does not function with web-based apps.


Charge stand*



NOTE *Contents may vary by product.

NOTE Both the charge stand and micro USB cable can be plugged into either a computer or wall charger. It is only necessary to plug the charge stand into a computer to update firmware.

USB Bluetooth adapter




USB LEDs	What they mean
Red and blue flashes	Pairing
Solid Blue	Pairing successful; Connected
Blue flashes	On a call
Solid red	Mute active
Purple flashes	Streaming music/media from computer

Connect and pair

Connect to PC

Your Bluetooth USB adapter comes pre-paired to your headset.

- 1 Insert the Bluetooth USB adapter into your laptop or PC.



- 2 Pairing is successful when you hear "pairing successful" and the USB adapter LED is solid blue.
- 3 **OPTIONAL: Headset call control** Some softphones require the installation of Plantronics Hub for Windows and Mac (plantronics.com/software) to enable headset control (answer/end and mute) functionality.

NOTE Plantronics Hub software also allows you to customize your headset's behavior through advanced settings and options.

Configure USB adapter

Your high-fidelity Bluetooth USB adapter comes ready to take calls. If you want to listen to music, you will need to configure your Bluetooth USB adapter.

Windows


- 1 To configure your Bluetooth USB adapter to play music, go to **Start menu > Control Panel > Sound > Playback tab**. Select **Plantronics BT600**, set it as the Default Device and click OK.
- 2 To pause music when you place or receive calls, go to **Start menu > Control Panel > Sound > Communications tab** and select the desired parameter.

Mac

- 1 To configure the Bluetooth USB adapter, go to **Apple menu > System Preferences > Sound**. On both the Input and Output tabs, select **Plantronics BT600**.

Pair to mobile device

- 1 To put your headset in pair mode, press and hold the power button towards the Bluetooth icon until you hear "pairing" and the headset LEDs flash red and blue.



- 2 Activate Bluetooth on your phone and set it to search for new devices.
 - **iPhone Settings > Bluetooth > On***
 - **Android Settings > Bluetooth: On > Scan for devices***

NOTE *Menus may vary by device.


- 3 Select "PLT Focus."

If necessary, enter four zeros (0000) for the passcode or accept the connection.

Once successfully paired, you hear "pairing successful" and the headset LEDs stop flashing.

NOTE Your headset can pair with up to 8 devices but only maintain 2 connections simultaneously; this includes the Bluetooth USB adapter.

- Pair USB adapter again
- 1 Insert the high-fidelity Bluetooth USB adapter into your laptop or computer and wait for your computer to recognize it.
 - 2 Put your headphones in pair mode.
 - 3 Put your Bluetooth USB adapter into pair mode by gently pressing and holding the pair button with a pen or paperclip until the Bluetooth USB adapter flashes red and blue.




Pairing is successful when you hear "pairing successful" and the Bluetooth USB adapter LED is solid blue.

Fit and charge

Wear on the right or left

To position the microphone on the right or left side, rotate the microphone boom up and over. Adjust the boom so it points to the corner of your mouth.




TIP Your headset senses when you change the microphone boom from one side to the other and syncs the audio and controls specific to each side.

Charge your headset


IMPORTANT Before using, charge the headset fully to reset the accuracy of the talk time prompts.

Charge your headset with the charge stand or the micro USB cable. The headset LEDs flash when charging. It takes up to 2 hours to fully charge your headset. The LEDs turn off once charging is complete.

NOTE Both the charge stand and micro USB cable can be plugged into either a computer or wall charger. It is only necessary to plug into a computer to update firmware.



Charge stand



Micro USB cable

Headset LEDs	Battery status
4–5 blue blinks	Battery high
2–3 blue blinks	Battery medium
1 red blink	Battery low
flashing red	Battery critical; Recharge headset

Check headset battery status

There are several ways to check your headset battery status.

- 1 Wearing the headset, tap the Call ☎ button and listen to the voice alert (smartphone only).
- 2 When not wearing the headset, tap any button except the Call button and observe the headset LEDs.
- 3 Place the headset in the charge cradle and observe the headset LEDs.

Load software

Some softphones require the installation of Plantronics Hub for Windows and Mac to enable headset control (answer/end and mute) functionality.

- 1 Install Plantronics Hub for Windows and Mac onto your computer by visiting plantronics.com/software.
- 2 Manage your headset settings with your computer or mobile device with Plantronics Hub for Windows and Mac or Plantronics Hub for iOS and Android, respectively (plantronics.com/software).

Plantronics Hub	iOS and Android	Windows and Mac
Call control for softphones		X
Change headset language		X
Update firmware		X
Turn features on/off	X	X
View user guide	X	
Battery meter	X	X

The basics



	Volume up/down
	Track backward*
	Play/pause music*
	Track forward*
	Active noise cancelling
	Charge port
	Active call = mute/unmute Idle = OpenMic (hear your surroundings)
	Headset LEDs for pairing, battery status, online indicator
	Call button ([])
	Power button
	Bluetooth pair button

NOTE *Functionality varies by application. Does not function with web-based apps.

Make/Take/End Calls

Answer or end a call


Tap the Call ☎ button.

Call back last call (smartphone)

To dial your last number you dialed, double-tap the Call ☎ button.

Voice dial (smartphone)

If your smartphone has a voice-enabled assistant, press and hold the Call ☎ button for 2 seconds and wait for the phone prompt and then tell the phone to dial the number of a stored contact.

Mute/unmute	While on an active call, choose: <ul style="list-style-type: none">• Tap the red Mute button• Take off/put on your headset while on an active call (requires active smart sensors)
Mute on reminder*	<p>* Plantronics Hub for Windows and Mac required (plantronics.com/software)</p> <p>If you have muted an active call and you start to speak, then a desktop notification reminds you that you are on mute. You can add a voice prompt notification by managing your mute features with Plantronics Hub for Windows and Mac.</p>
OpenMic	While not on a call, tap the red Mute button to activate OpenMic and hear your surroundings. Control the level of ambient noise you hear by adjusting the volume wheel.
Volume	Rotate the volume wheel  forward (+) or backward (–) to control the volume.
Play or pause music	Choose: <ul style="list-style-type: none">• Put on/take off the headset (requires active smart sensors)• Tap the Play/pause ► button <p>NOTE <i>Functionality varies by application. Does not function with web-based apps.</i></p>
Track selection	Tap the Forward button ► or Back button ◀ to control the track selection. <p>NOTE <i>Functionality varies by application. Does not function with web-based apps.</i></p>
Use sensors	Smart sensors respond when you put on or take off your headphones.


With active sensors	putting on the headset will:	taking off the headset will:
Call	answer the call	mute the headset
Music/media	resume music/media (if playing previous to taking off)*	pause music/media (if playing)*
Mute	unmute if on an active call	mute if on an active call

NOTE **Functionality varies by application. Does not function with web-based apps.*

Reset sensors

You may need to reset the sensors if they are not working as expected.



There are two ways to reset the headset sensors. Choose:

- With your headset powered on, charge your headset on the charge stand for 10 seconds
- Press and hold both the Mute  and Play/pause ►|| buttons for more than 4 seconds until the LEDs flash purple twice, being careful to not touch the earcup padding or allow it to come in contact with surfaces

Disable sensors

You can disable your headset smart sensors several ways:

- Manage sensors through Plantronics Hub software

- Hold both the Mute  and Call  buttons for more than 4 seconds until the LED flashes purple then red. Repeat to reactivate; the LED flashes purple then blue

NOTE *Sensors cannot be disabled while streaming audio.*

ANC


Active Noise Cancelling (ANC) reduces external noise and enhances your music and sound quality.

Your headset ships with ANC on. To turn ANC off, slide the switch away from "ANC."

More Features

DeepSleep Mode


If you leave your headphones powered on but out of range of your paired phone or USB adapter for more than 7 days, your headset conserves its battery power by entering into DeepSleep mode.

Once back in range with your phone or USB adapter, press the Call control  button to exit DeepSleep mode.

Answer calls from a second device

It's easy to answer calls from two devices (including softphone).

When on a call, you hear a ringtone notification of the incoming call from the second paired device.

To answer a second call from the other device, first tap the Call  button to end the current call and tap the Call button again to answer the new call. If you choose to not answer the second call, it will go to voicemail.

Change language

You can change the voice prompts language of your headset (for example "mute on").

- 1 Download Plantronics Hub for Windows/Mac at plantronics.com/software.
- 2 Dock your headset in the charge stand and plug it directly into your computer.
- 3 Disconnect your headset from other devices; this includes unplugging your USB adapter from the computer.
- 4 Open Plantronics Hub for Windows/Mac and go to **Settings > Language** to view language choices for voice prompts.

Update firmware

Firmware updates are designed to keep your headset current with the latest technology.

Update your firmware to:

- Change voice alert/command languages
- Improve performance
- Add new features to your device

- 1 Download Plantronics Hub for Windows/Mac at plantronics.com/software.
- 2 To update your **headset** firmware, dock your headset in the charge stand and plug it directly into your computer. Disconnect your headset from other devices; this includes unplugging your USB adapter from the computer.
- 3 Open Plantronics Hub for Windows/Mac and check the Updates tab for firmware update alerts.

TIP


- *Do not answer or place a call during the update*

What's in the box


Contents may vary by product.



Headset




Charge stand



Bluetooth USB Adapter




Carrying case



Micro USB cable

Accessories

Sold separately at plantronics.com/accessories.



Wall charger

Troubleshoot

When I use my headset with a softphone, the headset call control and mute buttons don't work.	<p>Check the following:</p> <ul style="list-style-type: none">• Make sure the softphone you are using is supported by viewing our software compatibility guide.• If required to enable headset control (answer/end and mute) functionality, ensure you have Plantronics Hub for Windows/Mac (v. 3.6 or later) installed. See Load software.
I can't unmute my headset when I'm on a softphone call.	Ensure that you have Plantronics Hub for Windows/Mac v. 3.6 or later installed.
<p>The headset sensors are not working as expected.</p> <ul style="list-style-type: none">• A call is not automatically answered when I put on my headset• Mute/unmute is not working when I take on/off my headset during a call• During a call, mute unexpectedly turns on.	If your headset sensors are not working as expected, you may need to reset the sensors. See Reset sensors .
During a call, nobody can hear me.	<p>Configure the headset as the recording/output default device.</p> <p>For Windows, go to Start menu > Control Panel > Sound > Recording tab. Select Plantronics BT600, right-click, select "Select as Default Device" and click OK.</p> <p>For Mac, go to Apple menu > System Preferences > Sound > Output tab and select Plantronics BT600.</p>
During a call, I can't hear anybody.	<p>Configure the headset as the playback/input default device.</p> <p>For Windows, go to Start menu > Control Panel > Sound > Playback tab. Select Plantronics BT600, right-click, select "Select as Default Device" and click OK.</p> <p>For Mac, go to Apple menu > System Preferences > Sound > Input tab and select Plantronics BT600.</p>
During a call, I get interference and drops in sound.	Your headset is configured for optimal performance during conference calls. Stereo telephony is on by default. To increase Bluetooth density, change the setting from stereo telephony to mono telephony by holding the Mute button for four seconds while not on a call, until you hear "Wideband stereo off." You can also change the setting in Plantronics Hub for Windows/Mac by going to Settings > Wireless > Extended Range Mode .
Music is not coming through my headset.	To configure your USB adapter to play music, see Configure USB adapter .
On my Mac, if I'm listening to streaming audio and take off the headset, iTunes starts playing when I put the headset back on.	This is a known issue. Turn off play/pause setting in the sensors tab of Plantronics Hub for Windows/Mac.
When I play music and a call comes in, the music is too loud or doesn't pause.	To configure your USB adapter to play music, see Configure USB adapter .

The headset talk time is not accurate.

Charge the headset fully to reset the accuracy of the talk time prompts.

I hear an echo when not on a call.

Check and see if OpenMic is on by pressing the red mute button on the boom when you are not on a call. Our exclusive OpenMic feature lets you control the level of ambient noise you hear.

Support

EN 0800 410014	FI 0800 117095	NO 80011336
AR +44 (0)1793 842443*	FR 0800 945770	PL +44 (0)1793 842443*
CS +44 (0)1793 842443*	GA 1800 551 896	PT 800 84 45 17
DA 80 88 46 10	HE +44 (0)1793 842443*	RO +44 (0)1793 842443*
DE Deutschland 0800 9323 400 Österreich 0800 242 500 Schweiz 0800 932 340	HU +44 (0)1793 842443*	RU 8-800-100-64-14 +44 (0)1793 842443*
EL +44 (0)1793 842443*	IT 800 950934	SV 0200 21 46 81
ES 900 803 666	NL NL 0800 7526876 BE 0800 39202 LUX 800 24870	TR +44 (0)1793 842443*

**Support in English*

For warranty details, go to plantronics.com/warranty.

NEED MORE HELP?

plantronics.com/support

plantronics®
Simply Smarter Communications™

Plantronics, Inc.
345 Encinal Street
Santa Cruz, CA 95060
United States

Plantronics BV
South Point Building C
Scorpius 140
2132 LR Hoofddorp, Netherlands

© 2016 Plantronics, Inc. Plantronics, Voyager, DeepSleep and Simply Smarter Communications are trademarks of Plantronics, Inc. registered in the US and other countries. Bluetooth is a registered trademark owned by Bluetooth SIG, Inc. and any use by Plantronics, Inc. is under license. All other trademarks are the property of their respective owners.

Patents: US 8,208,673; 8,494,153; CN ZL201530152759.7; ZL201530152785.X; EM 002700138; 002700146; IN 272226; 272227; KO 30-833989; TW D171945; patents pending.

205084-06 (04.16)