
SONY_®




Sound Bar


Startup Guide


HT-CT290/HT-CT291






Connecting with a TV







Note

Make sure that the HDMI cable is firmly inserted.
To view the USB content list on the TV screen, make sure you connect the system to the TV using HDMI cable.





3 Listening to the sound



To prevent interference when you use multiple wireless products, connect the subwoofer to the Bar Speaker using Secure Link function. For details, refer to the supplied Operating Instructions.

Press INPUT repeatedly until the input indicator for the device you want lights up. Then, press \triangle +/- repeatedly to adjust the volume of the system and press SW \triangle +/- repeatedly to adjust the subwoofer volume.

To listen to TV audio, select the program you want using the TV remote control.

Setup completed! Enjoy!

Please refer to the supplied Operating Instructions about the sound effects, and other functions.



Operating Instructions

Listening to music from a BLUETOOTH device (Pairing and connecting)



- Place the BLUETOOTH device within 1 meter from the Bar Speaker.
- 2 Press (pairing).
- BLUETOOTH indicator (blue) flashes quickly () == ().
- 3 Turn on BLUETOOTH function and select "HT-CT290/291" on the BLUETOOTH device.
- 5 Start playback on the BLUETOOTH device.
- 6 Adjust the volume.

Refer to the supplied Operating Instructions for details on other BLUETOOTH settings.

© 2017 Sony Corporation Printed in Malaysia