


■ Charging InkCase i7 Plus


InkCase



Battery Full

■ Battery Empty

■ Switching On InkCase i7 Plus



Press and hold the Power Button for 5 seconds, to switch on the InkCase i7

Note the Device ID at the bottom left corner of the startup screen during boot up. You will need this Device ID during the InkCase setup.

■ Switching Off InkCase i7 Plus

Method 1: Press and hold the Power Button for 5 sec to switch off.



Method 2:

Press the Power Button once for Power Menu. Select power off icon and tap Menu Button

■ Restarting InkCase i7 Plus

Press and hold the Power Button for 10 secs to reset an unresponsive InkCase i7 Plus


■ Standby Mode

Press the Power Button once for Power Menu, Select lock icon and tap Menu Button.



Press the Power Button again to unlock InkCase or exit Power Menu. Standby mode also locks the touch buttons from accidental clicks.


■ Navigating the InkCase i7 Plus



Tap on the Left or Right touch buttons on the InkCase to navigate to the previous or next display.



DOUBLE TAP on the Menu Button for Main Menu, use the Left and Right touch buttons to switch between various modes. Tap Menu Button once to select.



TAP ONCE on the Menu Button for Options Menu, use the Left and Right touch buttons to switch between various options. Tap Menu Button once to select.

■ Downloading InkCase App

Download "InkCase" app from iTunes App Store.



InkCase app enables you to:

- Connect InkCase to iPhone via
- Send images from iPhone to InkCase • Send eBooks to InkCase for
- eReading Access Live Information Center
- Save News articles

■ Setting Up InkCase With iPhone

Power/Lock Button

Menu/Enter Button

Right Touch Button

Magnetic Charging Port



Launch InkCase App. Select 'My InkCase' tab to setup your new InkCase i7 Plus. Pair InkCase i7 Plus and iPhone via Bluetooth in Device List.

You should recognize the Device ID from the startup screen.

Note: Make sure to allow all permissions for InkCase. Go to iPhone Settings > InkCase. Also set Location

■ Setting Up Live Information Center

Allow all permission for InkCase at Settings > InkCase.

Activities tracking: Open Health app > Sources > InkCase > Allow all

Reminders: Open Reminders app > Input tasks > Set tasks to priority '!', '!!' or '!!!'

■ Sending Images to InkCase i7 Plus



Click Photos tab in InkCase app. Select an image from the photo album or take a new photo. Crop and save image. Select saved image to send to InkCase i7 Plus.

■ Sending Ebooks to InkCase i7 Plus

Method 1 Import ebooks to InkCase app via

Method 2: Access ebook files via email or any file sharing app on the iPhone. Select ebook file and share to InkCase app.



Click Reader tab in InkCase app. Select the desired ebook and send to InkCase i7 Plus.

■ Sending News to InkCase i7 Plus

Navigate to any articles in iPhone's browser. Select the share button to send to InkCase i7 Plus.

Alternatively, you can also share it from any dedicated News apps such as CNN and BBC.



Navigate to Read Later tab in InkCase app and drag down to sync all articles to InkCase i7 Plus.

Deleting News: Click Read Later tab in InkCase app. Swipe left on article you wish to delete and select 'Archive'. Drag down to sync again.

■ Deleting Images from InkCase i7 Plus

Tap once on the Menu Button for Options Menu, use the Left and Right touch buttons to switch to delete icon. Tap Menu Button once to delete image.



A popup dialog box will appear, select tick icon and tap Menu Button once to

■ Deleting Ebooks and News from InkCase i7 Plus

Tap once on the Menu Button for Options Menu, use the Left and Right touch buttons to switch to delete icon. Tap Menu Button once to delete.

A book or news list will appear, navigate to the title you want to delete, tap Menu Button once to

■ Firmware Upgrade

Download the Firmware Upgrade Tool

Install the Firmware Upgrade Tool on your computer. Launch the Firmware Upgrade Tool, select desired language. Connect InkCase i7 Plus to the computer with the InkCase's magnetic USB cable.

If InkCase i7 Plus was not detected, Press and hold the Power Button for 10 secs. Follow on screen instructions to complete the firmware upgrade.

■ Specifications

- Supports iPhone 7 Plus Screen: 5.2" E Ink
- Resolution: 540 x 960
- Dimension: 167.4 x 83.7 x 13.3 mm
- Weight: 80gNavigation: 1 tact button, 3 touch buttons
- Connection: Bluetooth 4.0 BLE
 Standby Time: 5 days