RAGE Z90

USER MANUAL



FEATURES

- 1. Metallic headband inner structure.
- 2. Premium comfort.
- 3. 5.1 real sound.
- 4. Ozone atmosphere.
- 5. Detachable LED microphone.
- 6. Advanced in-line control.
- 7. Driver compatible with Windows 7, 8, 8.1 and XP.

BOX CONTENT

- 1. Headphone with mic + inline controller with a USB connector.
- 2. Magnetic controller base.

RAGE <mark>Z90</mark>

RAGE <mark>Z90</mark> DRIVER

INSTALLATION GUIDE

Rage Z90 is compatible with PC.

1. Go to www.ozonegaming.com, search for Rage Z90 and download the drivers and software.

2. Using the USB connector, plug the headset into any free USB port. Install the software following all the instructions in the installation window. Please note that the headset features an additional soundcard which must be configured in the system settings as the default device for audio playback and recording.

3. Once the installation have been finished, open the Rage Z90 software and configure the device to suit your playback and recording preferences.


CONFIGURATION

In the tray, click OZONE logo to pop-up the Rage Z90 Control Panel






Customize your own setting via adjusting the functions within control panel: 1. MAIN CONTROL: You can set up the number of speakers and adjust the Master, Front, Rear and Center Volume and sample Rate of speakers and microphone.




2. EQUALIZER: Enable the Equalizer and set it up to your personal preference or use one of the predefined settings for the different game styles.



You can also save you own EQ settings and you will have them available under the "MANUAL" drop down menu.

CREATE YOUR PE	ERSONAL PRES	ET:		
MANUAL	6666	-		
			17	
				/
			1	9

3. **ADVANCED SETTINGS:** Here you can set different features like Dynamic Bass, Audio Enhance, SoundLevel Normalization for the output device and Incoming Voice Definition or Voice FX for the input device.



4. RUDIO PROFILES: You can select, modify and store up to 5 different profiles and switch your custom settings quickly.

							e mare	
	P2 Default2	P3	Default3	P4	Default4		P5 De	fault5
	SETTINGS SUI	MMARY	Stereo	Quadrophonic	5.1 Surround	EQ	DB SL-N	VoiceFX
OK APPLY CANCEL	OZONE RAGEZ90 DRIVER V 1.0							

RAGE Z90 INLINE CONTROLLER


You can configure below settings through the inline controller:

- 1. Adjust the speaker master volume as needed. (Volume wheel).
- 2. Mute the playback. (Wheel center mute button).
- 3. Mic. mute function: mute the mic with just one click and easily turn it back ON when required. (Side mute mic button).
- 4. Switch on/off the Ozone Atmosphere. (LED side switch).
- 5. Adjust the volume of every channel independently with the center, front, rear and sub sliders. (Independent channel volume sliders).

* LED indicator on controller: RED LED blinking when POWER ON



RAGE Z90 MIC PLUG & UNPLUG



Insert the mic connector into the headset paying attention to the shape of the case and plug it. Once plugged turn the mic 90° to avoid detach it by error.

To detach the mic first turn the mic 90° in the other direction and unplug it.

WEEE NOTICE:

Symbol for Separate Collection in European Countries. This symbol indicates that this product is to be collected separately. The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.





ITS All about EVO/UTION

WWW.ozonegaming.com