


# Washing




## WASH&DRY SHOES RACK



Perfect washing and drying results, protecting your shoes and your home appliance. The Wash&Dry Shoes Rack elevate your shoes care routine with a solution for effortless shoes cleaning and drying, using this accessory to quickly wash and dry your shoes in your washing machine and dryer. No worries about drum damage or noise during cycles as the rack always keeps your shoes safe in place. The accessory is universal, so it ensures a seamless fit in various washing machine and dryers models.



**Built to Last:**  
The Shoes Rack is crafted from highly durable and resistant materials, guaranteeing long-lasting performance and reliable shoes care. Rest assured that your investment in quality footwear is matched by an accessory that withstands the rigors of washing and drying cycles, ensuring your shoes stay protected and in prime condition.



- Space-Efficient Design: Maximize washing machine and dryer space efficiency as the compact Shoes Rack keeps shoes in place during cycles.
- When not in use, its compact design makes storage a breeze, keeping your laundry area organized and clutter-free.



For the best washing and drying results



Gentle with your shoes



No noise or damage to the drum

**CSRU1102 35602876 EAN 8059019087795**  
6,5 x 6 x 35 cm

RECOMMENDED BY



ROSIÈRES



Haier