



**ALIGATOR**



Aligator Watch GPS

Instructions for use

# CONTENTS

<b>Important instructions</b> .....	4
<b>Controls</b> .....	6
<b>Commissioning</b> .....	7
Charging .....	7
Turning on and off.....	7
<b>Control basics</b> .....	8
<b>Connecting the watch to your phone</b> .....	9
Download the GloryFitPro app.....	10
Connect your watch to your phone .....	11
<b>Viewing measured data on your phone</b> .....	12
<b>Setting the watch</b> .....	13

<b>Setting alerts on your watch</b> .....	13
<b>Phone and music functions in watches</b> .....	14
How to make calls on your watch .....	15
<b>Setting the appearance of the dial</b> .....	16
Changing the appearance of the watch face ...	17
Selecting additional watch face designs in the app .....	17
<b>Setting the user function of the button ②</b> .....	18
<b>Quick Control and Shortcut Settings</b> .....	19
<b>Setting the display to light up by raising your hand and touching it</b> .....	20
<b>Always ON display function</b> .....	20
<b>Training and location recording using GPS in watches or apps</b> .....	21

<b>Modifying personal settings and data</b> .....	22
<b>Find your phone using your watch and vice versa</b> .....	23
<b>Waterproof 5 ATM</b> .....	24
<b>Troubleshooting</b> .....	25
Notifications are not displayed on the watch ....	25
The watch does not connect .....	26
The watch cannot be charged with a powerbank .....	26
<b>Safety and ecology</b> .....	27
Built-in battery .....	27
Instructions for safely removing the battery ....	27
Used electrical equipment .....	28
<b>Declaration of Conformity</b> .....	29

Thank you for purchasing an Aligator product. Please read this manual to learn how to use your new smartwatch.


## **Important instructions**

- Handle the product and accessories with care, protect them from mechanical damage and dirt.
- Protect the product and accessories from extreme temperatures.
- Do not throw the product into a fire or expose it to temperatures above +60°C, there is a risk of explosion. The product contains a built-in battery.
- Protect the product and accessories from falling to the ground.

- The product does not contain any user-serviceable parts, never disassemble the product or accessories.
- Turn off the product in an aircraft unless expressly permitted to use it.
- Do not use the product near explosives.
- Keep out of reach of children and do not allow them to play with the product. It may contain small parts that could cause choking or other injury.
- Software and hardware are continuously upgraded. The manufacturer therefore reserves the right to change the manual and individual functions without prior notice.

For more information, instructions, and video tutorials on how to set up your smartwatch, visit:  
**<http://www.aligator.cz/awgps>**

# Controls



- ① **Power On/Off and Display Light/Dimmer Button**
- ② **Back/User Function Button**
- ③ **Sports and training measurement menu button / long press – stop training**

# Commissioning

## Charging

Before using the watch for the first time, charge it using the included magnetic adapter, which attaches to the contacts on the back of the watch using magnets. Plug the other end of the adapter into a suitable USB socket. The battery charge status will be shown on the display.

## Turning on and off

To turn the watch On/Off, press and hold the button **1** until the watch turns On/Off. You will still need to confirm the shutdown on the phone display.

If the QR code is displayed on the display after turning it on, you can cancel its display by long pressing the display.

## Control basics

The watch display is dimmed by default to save battery power. To activate the watch display, press any button. The display will dim itself after a short period of time, or you can dim it by pressing the button ①.

To display **the function menu, slide your finger across the display from right to left** (the opposite movement will return you). By default, a list of functions is displayed. To select a function, tap the corresponding icon in the menu.

**By sliding your finger across the display from bottom to top**, you can scroll through the screens of individual functions and measured values.

**To go back one level in the menu**, press the button ② or swipe the display from left to right.

**To quickly view notifications**, swipe from left to right on the home screen (the opposite motion will go back).

**To quickly control and set up**, swipe from top to bottom on the home screen (the opposite motion will go back). You can quickly switch watch modes, adjust brightness, vibration, and more.

**Press the button** ③ to display the sports menu and training activity measurement.

## **Connecting the watch to your phone**

To take full advantage of all features, you need to connect your smartwatch wirelessly to the app on your phone. Download and install the app **GloryFitPro** on your phone:

## GloryFitPro



***ATTENTION! After installation and first launch, the application will need to allow all permissions that you will be asked for several times, otherwise it will not function properly.***

*For more accurate records and value calculations, we recommend entering your information as it is.*

After all permissions are granted, the profile page will open. Enter your details – gender, height, age, etc. Complete the settings by clicking the button with the “**confirm**” icon at the bottom.

## **Connect your watch to your phone:**

1. In the app, go to the watch settings screen by tapping the icon at the bottom of the screen.
2. Bring the watch close to your phone and tap the “**Add device**” button.
3. The app will display a list of found devices.
4. Tap to select the **Aligator Watch GPS** device
5. The watch will pair. Done!

## Viewing measured data on your phone

After pairing the watch with your phone, launch the **GloryFitPro** app and tap the first icon from the left at the bottom of the app screen.

A screen will appear with information downloaded from the watch – step count, sleep, heart rate recording, blood pressure, blood oxygenation, training activity recording and other data.

By tapping the tab of a measured value, you can also view records from previous days, or select a date from the calendar for which you want to find out information.

***Data is continuously downloaded from the watch via a wireless connection, but the watch must be within range of the phone – within a few meters.***

## Setting the watch

The watch is set up using the **GloryFitPro** app on your phone. Tap the watch icon at the bottom of the app screen.

You can now configure all watch settings (change the watch face, alarms, notifications, and many other features).

## Setting alerts on your watch

An important feature of the watch is its ability to notify you of incoming calls, SMS messages, social media messages, and notifications from other apps.

1. Go to the device screen by tapping the icon with the symbol at the bottom of the app.
2. Select **Notifications**.

3. A selection of notifications will appear, which you can activate by tapping the switch next to the name.
4. When enabling notifications, the app will request various access permissions – access must **be granted** for the app to function properly. When setting up for the first time, a screen for granting access to notifications will also appear. Turn on the switch next to the **GloryFitPro** app.

## Phone and music functions in watches

Thanks to the built-in microphone and speaker, the watch allows you to make calls and listen to music. When this function is activated, it acts as an advanced hands-free kit, allowing you

to answer and end calls and dial phone numbers and contacts directly on the watch.

**The phone function on the watch can be easily turned On/Off** using the quick control – swipe down on the main screen and press the headphone icon.

***ATTENTION! After connecting and activating the phone function, music and audio playback from your phone and voice assistant control are also redirected to the watch.***

## How to make calls on your watch

- Tap the red icon to reject an incoming call, or the green icon to accept it.



- Tap the phone icon to switch the phone call between the watch and the phone.
- Adjust the volume by tapping the speaker icon.
- The microphone can be turned On/Off using the microphone icon.



## Setting the appearance of the dial

**Aligator Watch GPS** offers a wide range of watch face designs. Several designs are pre-installed directly in the watch. Thanks to the app, dozens of other designs are available, including the option to set your own photo or image directly on the watch face background.

## **Changing the appearance of the watch face**

1. Press your finger on the watch display until the current watch face shrinks.
2. Move your finger sideways to select from the available watch faces.
3. Confirm the selected watch face by touching the screen.

## **Selecting additional watch face designs in the app**

1. Go to the device screen by tapping the clock icon at the bottom of the app and select **Watch Faces**.

2. The watch faces that you already have installed on your watch and that you can install will be displayed.
3. Tap the watch face you want to use and then tap the **“Download”** button below the watch face.
4. The watch face will be downloaded and then installed on your watch. You can follow the process on your phone’s screen.

*In the overview of your installed watch faces, you can also set your own photos or images as the background of your watch face.*

## Setting the user function of the button ②

Aligator Watch GPS allows you to set a custom function for button ② (**Back**). To set, swipe from

right to left, select from the function menu  
**Settings → Button down.**

Then select the desired function, which will be activated when you press the button ②.

## **Quick Control and Shortcut Settings**

Swipe down from the top of the home screen to open the watch's quick controls and shortcuts. In addition to the default shortcuts, you can also set your own. Just swipe from right to left in the shortcut overview, tap the icon with the **+ symbol** and add the desired shortcuts. You can set up to 11 custom shortcuts in total.

## Setting the display to light up by raising your hand and touching it

To set when the display automatically turns on, go to **Settings** → **Display and Brightness** in the features menu and turn on or off wake on **wrist raise** or **touch**.

## Always ON display function

The modern OLED display technology allows for a permanent display of the time in power saving mode under certain circumstances. The time will then always be visible on the watch without having to turn on the display. Please note that the battery will drain faster.

To set this, go to the function menu:  
**Settings → Always ON display.**

## **Training and location recording using GPS in watches or apps**

The watch allows you to accurately track your training thanks to its built-in GPS. When running, cycling, or doing other outdoor activities, the watch records not only the usual parameters, but also your route, speed, and distance in real time. After completing your workout, you can view your route in the mobile app, analyze your performance, and track your progress.

Training can also be recorded directly using the **GloryFitPro** app on your phone. In this case, the watch acts as a step and heart rate sensor, and your training will be recorded directly in the app.

To start training on your phone, press the first **Sports** icon at the bottom of the screen in the **GloryFitPro** app. Tap the selected sport and press the **Start** button. Training recording will start on your phone.

After finishing your workout, the training data will be saved and you can review the route on the map and other information in the calendar.

## **Modifying personal settings and data**

To edit your personal information and change some other app settings, tap the icon on the right at the bottom of the screen – the **My Profile** screen will appear.

Now you can set your weight, age, and other information about yourself, as well as your daily goal.

## Find your phone using your watch and vice versa

If your watch is connected to your phone, you can easily find it using your watch. Select **Settings** → **Find Phone** from the watch's feature menu. You can then tap the icon on the watch screen to play a sound on your watch.

If you are looking for your watch, launch the **GloryFitPro** app on your phone, go to the watch settings screen, and select **Settings** → **Find Watch**. The watch will light up, play music, and vibrate.

***ATTENTION! Vibration must be enabled on the watch and the battery must not be dead. Otherwise, only the watch screen will light up.***

## Waterproof 5 ATM

**Caution! Never use the watch in salt water and/or hot water.** The water resistance specifications apply only to fresh water at normal temperatures up to 28°C.

The watch is designed to be water resistant to 5 ATM, but we strongly recommend that you avoid contact with water as much as possible.

During use, microscopic cracks may appear in the seal as a result of impact or wear and tear on the case. In such cases, water may enter the case and cause damage that is not covered by the warranty.

Pressurized or hot water may penetrate the watch and cause damage that is not covered by the warranty.

Never press the button when the case is in contact with water, as this may cause water to enter and damage that is not covered by the warranty.

## Troubleshooting

### **Notifications are not displayed on the watch**

Please check that you have enabled the **GloryFitPro** app to access notifications according to these instructions (see the chapter on **Setting alerts on your watch**). Alternatively, open your phone settings, enter “**access to notifications**” in the search field, and check that access is enabled for **GloryFitPro**.

## **The watch does not connect**

If you are unable to connect your watch to your phone, try turning Bluetooth off and on again on your phone and restarting this phone. If your watch doesn't connect, try searching for it again in the app. If your watch doesn't connect, reset your watch – swipe from right to left on your watch, tap the **“Settings”** icon, then **“System”** and select **“Reset”**. Then restart your phone and reconnect your watch in the app as described in the **Connecting the watch to your phone** chapter.

## **The watch cannot be charged with a powerbank**

The charging current of a watch is very small. Therefore, some power banks mistakenly interpret the connected watch as a phone that is already charged and automatically turn off charging.

# Safety and ecology

## Built-in battery



The product contains a built-in single-cell lithium battery, which does not belong in regular municipal waste and may contain substances that are harmful to the environment! Once the product has reached the end of its service life, the battery can be removed and handed over for further ecological processing.

## Instructions for safely removing the battery

*(by the user or a qualified professional independent of the seller)*

Make sure that the battery is completely discharged (if necessary, let the watch discharge completely first).

Carefully pry off the back cover of the watch with a knife or chisel. Risk of injury! Disconnect or cut the battery leads one at a time with scissors to prevent short circuits. Carefully remove the battery so as not to puncture or deform it – risk of electrolyte leakage, short circuit, and injury! Observe safety rules and use protective equipment, or have the work done by a professional!

## **Used electrical equipment**

Never dispose of the product in regular municipal waste, as it may contain substances that are hazardous to the environment! After use, it must be taken to the appropriate collection point, where it will be recycled or disposed of in an environmentally friendly manner. Contact your dealer or local authority to find out where such a collection point is located, or you can return it

directly to the dealer or to one of the branches of ADART COMPUTERS s.r.o.

Disposal of the product in contravention of these instructions is illegal!

## Declaration of Conformity

ADART COMPUTERS s.r.o. hereby declares that the Aligator Watch GPS radio device, type G56, complies with Directive 2014/53/EU.

The full text of the EU Declaration of Conformity is available on the following website:

**[www.aligator.cz/awgps](http://www.aligator.cz/awgps)**

Copyright © ADART COMPUTERS s.r.o.  
Čimická 717/34, CZ-Prague  
gpsr@adart.cz | **[www.aligator.cz](http://www.aligator.cz)**

