


**BOOX Poke Series**  
快速使用说明书


详细说明请参见内置电子书《用户手册》或官网技术支持  
www.boox.com

**BOOX Poke Series 智能阅读系列**

**产品配件:**




**选配 (用户需另行购买):**



01

**BOOX 智能阅读系**

**安全使用指南:**




**声明:**

限于篇幅, 本《快速说明》中所包含的信息并不完整, 请以相关型号《用户手册》具体信息为准。产品图片与实物可能有细微区别, 效果演示图和示意图仅供参考, 有关产品的外观 (包括但不限于颜色) 和功能, 请以实物为准。广州文石信息科技有限公司 (Onyx International Inc.) 保留对包含在本《快速说明》及《用户手册》中的产品规格和内容做出更改的权利, 如有更改, 恕不另行通知。

02


**接口说明:**



① 返回键


03

**界面功能说明:**



05

**触控操作说明:**



06

**常见问题:**

**1.如何开机**

1.1 关机状态下, 长按开关键2~3秒, 进入开机界面, 进度条完毕即进入操作界面;

1.2 开机状态下, 长按开关键2秒, 调出菜单, 选择“关机”;

**2.如何充电**

2.1 通过数据线连接阅读器和电脑数据线进行充电;

2.2 通过适配器 (选配) 连接数据线和阅读器, 接交流电插座进行充电;

2.3 充电时开关键指示灯亮起, 充满后指示灯熄灭;

2.4 充电时间大约3小时;

**3.如何传输数据**

3.1 通过数据线连接阅读器和电脑进行数据传输;

3.2 通过WiFi无线连接电脑手机助手APP进行数据传输;

3.3 通过WiFi直接登录内置浏览器访问网页进行下载数据或在线阅读;

3.4 通过WiFi直接登录阅读APP进行数据下载或在线阅读;

**4.如何升级**

4.1 下载升级update.upx 装入本机存储根目录进行地升级;

4.2 通过OTA进行在线升级。

注: OTA仅部分地区支持, 具体请咨询英文客服。

**5.如何保护设备**

5.1 日常使用尽量配备硬壳书套, 避免屏幕受到直接撞击、挤压;

5.2 不使用时尽量将屏幕向下扣放在水平面上, 勿在屏幕和水平面之间夹硬物;

5.3 存放时避免在阅读器上方堆积重物;

5.4 远离各种液体。

中国制造  
©广州文石信息科技有限公司, 版权所有


高 : 128mm

总宽 : 648mm 单张宽度 : 81mm


**BOOX Poke Series**  
Quick Start Guide

www.boox.com

**Product & Accessories:**




**Optional Accessories:**



01

**Safety:**




**Declaration:**

This guide can not contain enough information limited pages, please refer to the User Manual of each model for detail instruction. Product pictures in this guide are for reference only. Product ID including but not limited to colors and functions are subject to the actual product.

Onyx International Inc. reserves the right to modify the content of the Quick Start Guide and User Manual without further notice.

02


**Front View:**



① BACK

03


**Back View:**



② Power ③ Micro USB Port


04

**Interface Introduction:**



05

**Touch Guide:**



06

**FAQS**

**1. How to turn on/off the device**

1.1 When your BOOX is off, press power button for 3-5 seconds to turn the device on;

1.2 When your BOOX is on, press power button for 2 seconds to turn the device off;

**2. How to charge**

2.1 Recharge your BOOX by connecting it with PC directly;

2.2 Recharge your BOOX by connecting it with adapter(optional accessory);

2.3 Orange light is on when your BOOX is charging; the light will be off after battery is fully charged;

2.4 Full single charge will take around 3 hours;

**3. How to transfer data**

3.1 Transfer data by connecting your BOOX with PC via Cable;

3.2 Transfer data by third-party sync apps between PC and the device via WiFi;

3.3 Download data or read online by browsing via WiFi;

3.4 Download data or read online by Log-in of reading APP via WiFi;

**4. How to update locally**

4.1 Download the update package and put it into root directory of local storage ;

4.2 Update your firmware via OTA online ;

Note: 1. OTA update only supports some countries or areas, Please consult the local distributor.

2. Please connect the device with power source or PC to make sure of enough power for update.

**5. How to preserve your BOOX**

1. Use hard cover to avoid direct shocking or pressing against the screen;

2. Put the screen side downwards when your BOOX is not in use; do not put anything in-between of the screen and other flat surface;

3. Dont pile up or store heavy stuff over the device;

4. Keep your BOOX away from all types of liquids.

Made in China  
©Onyx International Inc. All rights reserved.