

BONECO healthy air

F100 MANUAL



READ AND SAVE THESE INSTRUCTIONS

Gebrauchsanweisung	3	Bruksanvisning	91
Instructions for use	11	Upute za uporabu	99
Mode d'emploi	19	Lietošanas instrukcija	107
Istruzioni per l'uso	27	Naudojimo instrukcijos	115
Gebruiksaanwijzing	35	Kasutusjuhend	123
Instrucciones de uso	43	Návod k použití	131
Használati útmutató	51	Návod na používanie	139
Instrukcja obsługi	59	Navodila za uporabo	147
Bruksanvisning	67	Руководство по эксплуатации	155
Käyttöohjeet	75	取扱説明書	163
Brugsanvisning	83	사용 설명서	171

INSTRUCTIONS FOR USE BONECO F100

TABLE OF CONTENTS

Technical data	13
Introduction	14
Items included	14
Overview and part names	15
Start-up	16
Positioning tips	17
Location	17
Notes on performance	17
Air-conditioning System (AC)	17
Fresh air	17
Cleaning	18
Safety instructions	18
Cleaning the housing	18
Cleaning the fan blades	18

TECHNICAL DATA

Technical data*	
Model	BONECO F100
Power supply voltage	220-240V ~ 50 Hz
Power consumption	20 W (max. level)
Operation noise level	55 dB(A) (max. level)
Air flow	610 m³/h
Air-speed	4.1 m/sec
Dimensions L×W×H	202×207×238 mm
Weight	1.6 kg

^{*} Subject to change

INTRODUCTION

DEAR CUSTOMER,

Congratulations on your purchase of the BONECO F100 Air Shower Fan. This high-performance unit seamlessly adapts to meet your needs. When set to the lower output levels, it provides a pleasant breeze in your home on hot days. On the other hand, if you use an air-conditioning system, the unit's powerful fan distributes the air throughout the room ensuring a uniform temperature.

In developing the BONECO F100, low-maintenance operation and durability were of primary importance. The fan blade's one-of-a-kind shape creates a uniform air flow using minimal energy, which is also good for the environment. The elegant design harmonizes with any decorative style so that you can use your BONECO F100 throughout the entire year.

We hope you enjoy your new BONECO F100!

ITEMS INCLUDED



BONECO F100 Air Shower System with power cord



Manual



Safety instructions


OVERVIEW AND PART NAMES



- Power cord connection
- 2 Output level display
- 3 Touch control pane

START-UP









POSITIONING TIPS

LOCATION

In order to create a comfortable climate, you should not point the unit directly at your face or your body.

NOTES ON PERFORMANCE

The BONECO F100 is equipped with a high-performance fan that can move large amounts of air. Making use of this feature: Guide the air in a specific direction to achieve a uniform room climate. The following examples illustrate how to do this.

AIR-CONDITIONING SYSTEM (AC)

An air conditioner distributes the temperature in various ways. Use the BONECO F100 to move the warm air towards the air-conditioning system. This can be done directly or indirectly via air circulation, as shown in this image.




FRESH AIR

The BONECO F100 helps you achieve better ventilation indoors. If cross-ventilation is not created, guide fresh air directly from the window into the desired room.



CLEANING

SAFETY INSTRUCTIONS



Do not use alcohol or corrosive cleaning agents for cleaning.

CLEANING THE HOUSING

The BONECO F100 is designed for low-maintenance operation, even after years of use. In most cases, a dry cloth can be used for cleaning.

If stubborn dirt is present, clean the housing using a damp cloth. Add a small amount of dishwashing detergent to the water.

CLEANING THE FAN BLADES

 Unscrew the safety screw on the underside of the housing.



Remove the front grill by turning counterclockwise slightly.



Unscrew the safety screw in the middle by turning it clockwise.



- 4. Remove the fan blade and clean it with a damp cloth.
- Put the unit back together by following the steps in reverse order.
- Attach the front grill with the safety screw. When doing so, pay attention to the position of the screw on the front grill.









www.boneco.com