

66mm 66mm 66mm MOUNTING OPERATION AUTO SAFE MODE To preserve batteries when power is low, the light will enter low output flashing mode for 1 hr. Safe mode cannot be override. Replace the batteries for maximum performance. Attach strap to one bracket hook. Pull strap over the post and attach to hook. Place light on bracket, twist clockwise into the groove. Power But 1. Press to power on. Press Mode 1 Mode 2 FL1 FL2 Understand country lighting laws and regulations before us
Do not shine directly in the eyes.
Do not submerge the battery or the whole light into water.
Do not dismantle the light which will void warranty.
Do not leave the light on and unattended.
Keep the light away from fire and combustible materials. 2. Press to choose modes in cycle. 1 1 DAY FLASH (DOUBLE BLAST) WARRANTY WARKANIY MOON Lights are covered by a ONE YEAR LIMITED WARRANTY from the date of purchase is free from defects in material and warkmanship. This warranty does not apply to damage due to heat, physical damage resulting from abuse, neglect, improper repair, improper fit, or alterations of the future. This covers the lights and cables only. Power Button For more information, please contact us at **cs@moon-sport.com** 3. Press 1 sec to power off. Press 1sec \*\*With Mode Memory Function: the light resumes previous mode upon next usage WA-MOON-MERAK-FRONT-1705

WA-MOON-MERAK-FRONT-1705

80mm