



SADES[®]
GROWING TOGETHER WITH GAMERS

SADES PEGASUS

USER MANUAL



The product user guide contains product features, uses and operating procedures. Read the user manual carefully to get the best experience and avoid unnecessary damage. Keep this manual for future reference. Strictly comply with applicable laws and regulations at the place of use.

Importer: Alza.cz a.s., Jankovcova 1522/53, 170 00 Prague 7, www.alza.cz




Thank you for purchasing the SADES Pegasus. Please read the provided instructions carefully before assembling your device, and strictly follow the manual in regards to the device's operation and use.




NOTES:

1. Please make sure the product does not get in contact with fire, direct sunlight and wet environments.
2. Do not put the chair on high or unstable places to avoid the danger of falling.
3. Put the chair on flat ground.
4. Pay attention to your kids when they are climbing the chair.
5. Please pay attention to the natural loosening of the bolts after long-term use, avoid sharp things scratching the chair.
6. Please avoid excessive tilting to prevent the danger of falling.
7. The full installation takes 30-40 minutes.

Accessories







- | | |
|---|--|
| 1. Back Rest | 2. Seat |
| 3. Frog Mechanism | 4. Five Star Base |
| 5. 2 Recliner Covers | 6. 5 Wheels |
| 7. Gas Spring Cover | 8. Gas Spring |
| 9. 4 Hexagonal Socket Bolts (pre-mounted) | 10. 4 Hexagonal Socket Bolts (pre-mounted) |
| 11. 2 Small Bolts, 2 Screw Covers | 12. Headset |
| 13. Cushion (pre-mounted) | L Shape Wrench provided. |


Please strictly follow all the installation steps. Accessories should be installed properly before locking them in place with the related screws. Left and Right signs correspond to your left and right side when you sit in front of the table.

Assembly Guide

STEP 1: PUT THE BACK REST AND SEAT TOGETHER

Put the back rest and seat together as shown in picture 1. Pay attention to the spot marked in red, which needs to be aimed at the bolt holes.

REMOVE THE PRE-MOUNTED BOLTS ON THE BACKREST BEFORE PERFORMING STEP 1!
The two bolts are located on each side of the back rest. Please aim at the bolt holes when putting the back rest and seat together.



STEP 2: LOCK THE BACK REST AND SEAT

Lock the 4 bolts on the left and right side in place as shown in picture 2.

Begin on the right side, where the tilting handle is located. Screw both bolts on the right side half way in and then screw in the two bolts on the left side. Afterwards, tighten the bolts on both sides.



STEP 3: INSTALL THE RECLINER COVERS

Attach the lower snap button first. Lock the screw into the hole on the recliner cover, and then attach the screw cover onto it.




STEP 4: INSTALL THE MECHANISM


Use the bolts to lock the mechanism and the seat together, make sure the bolts are screwed in tight.

The bolts are pre-mounted on the seat, please remove them and then lock the mechanism and seat together with the bolts. Please make sure the direction of the mechanism is the same as on the diagram.


Lastly, install the handles. Please make sure that the direction of the handles is the same to the diagram when you're installing them.



STEP 5: INSTALL THE WHEELS




STEP 6: INSTALL THE GAS SPRING



Please remove the protective cover at the top of the gas spring before installing it.

STEP 7: PUT ON THE GAS SPRING COVER



STEP 8: PUT THE CHAIR BODY ON THE GAS SPRING

Aim at the top of the gas spring and the hole of the mechanism, then put the chair body down.



Warranty Conditions

A new product purchased in the Alza.cz sales network is under warranty for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide the original proof of purchase with the original date of purchase. Copies of proof of purchase of the product, altered, supplemented, without the original data or otherwise damaged proof of purchase of the product will not be considered as proof of purchase of the claimed product.

The following are considered to be a conflict with the warranty conditions, for which the claimed claim may not be recognized:

- Use of the product for a purpose other than that for which the product is intended or failure to follow the instructions for maintenance, operation and service of the product.
- Damage to the product due to a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (eg during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, such as sunlight and other radiation or electromagnetic fields, fluid intrusion, object intrusion, mains overvoltage, electrostatic discharge voltage (including lightning), faulty supply or input voltage and inappropriate polarity of this voltage, chemical processes, for example used power supplies, etc.
- If modifications, alterations, design changes, or alterations have been made to anyone to change or extend the product's features over the purchase or use of non-genuine components.