# Baseus Lovely Bluetooth Folding Bracket Selfie Stick WS-18026

Thank you for buying Baseus Lovely Bluetooth Folding Bracket Selfie Stick. Please, refer to this guide in detail and ensure safe and satisfactory operations. Also, keep this guide properly for future reference.

### <u>Parameters</u>

Battery capacity: 3V/120mAh (CR1632)

Size: 20.5cm, extends up to 65cm

Weight: about 155 g

Bluetooth version: 4.2

Applicable models: phones with diagonal size up to 6.5 inches (max width: 85mm)

# **Instructions for Use**

## Bluetooth Pairing

Long press the camera button for two seconds to start it up and the indicator will be green for three seconds before entering the pairing mode. Turn on the Bluetooth on the mobile phone and get ready for searching. Tap on "Baseus WS-18026". After the connection is successful, the green light will be solid on.

#### Shutdown

- 1. If there is no operation within 10 minutes after start-up, it will automatically enter the sleep state, and if there is no operation within 30 minutes after that, it will automatically shut down.
- 2. In the started and sleep states, long press the camera button for three seconds to turn it off, and the indicator will fast blink for three seconds and then go out.

## Opening the Cell Phone Chuck

Side up the product and turn the back mobile phone holder downward by 90 degrees to open it, and then turn the mobile phone chuck clockwise by 180 degrees to make it face forward.

#### Fixing Cell Phone

Rotate the chuck of the mobile phone to the appropriate position and pull open the chuck handle to secure the mobile phone on it.

# **Taking Photos**

Press the camera button to take a photo.

Note: Due to the compatibility problems of a very few models, in case that photos cannot be taken normally, please set the volume key function of the mobile phone as the shutter before taking photos.

## Using a Tripod

Open the bottom tripod, push the control lever upward and place the tripod on a stable horizontal plane to take photos.

# Separate Bluetooth Remote Control

Effective control distance: Max 10 meters. There is a battery compartment at the bottom of the remote controller. Please use the battery (CR1632) required for this product.

## <u>Tips</u>

- 1. If it is not used for a long time after starting up, it is recommended to shut it down manually to save power;
- 2. In the sleep state, short press the camera button, the indicator light will be on, then the green light flashes to indicate that the Bluetooth pairing state is entered;
- 3. When the battery is low, the indicator light will flash red. Please replace the battery in a timely manner;
- 4. When shooting with the tripod, please place it stably to avoid the cell phone falling down:
- 5. This product is not a toy. Children need to use it under the guardianship of adults;
- 6. Do not put the battery into the fire, otherwise it will cause fire and explosion of battery;
- 7. The improper use of the product may easily cause the damage of product itself or may endanger personal and property safety;
- 8. The company shall not be liable for any personal or property damages caused by improper use of the product by consumers in violation of the product instructions.