

Firmware updates

Dear Customers,

To help you get up to speed and use your Tesla receiver, please find below the procedure to update your product to the latest firmware.

The latest firmware can be found here:

<https://www.tesla-electronics.eu/tesla-te-300/> in the "Downloads" section.

The update process is very simple and takes no more than a few minutes. After downloading the firmware from the link above, save it to a USB flash drive with sufficient capacity. Insert the flash drive into the USB input found on the back of the receiver. The receiver must be switched on. After that, perform the FW update according to the procedure below:

1. Press the USB button on the remote control.
2. Press the left navigation button on the remote control to move to the "Software" field.
3. Use the top/bottom navigation buttons to move the cursor to the sw position in the list of files you have on the USB drive.
4. press the OK button and use the left/right navigation button to select "YES" and press the OK button to start the update.
5. Wait for a few minutes for the update to complete (the receiver will be in the factory state when the update is complete).
6. Reset the receiver.