

● 8mm T3.8 UMC FISH-EYE CS II (for Cinema)

Instruction Manual

Thank you for purchasing our lens.

We believe that this new 8mm T3.8 UMC FISH-EYE CS II lens for video recording will give you a special photographic experience.

Advantages of the 8mm T3.8 UMC FISH-EYE CS II

1. Image size of digital APS-C (1:1.5x).
2. 180° wide angle of view for 8mm of focal distance for APS-C for the first time in a FISH-EYE lens.
3. When the hood is removed, you can get almost real images from the camera with 35mm of image format.
4. With its stereoscopic projection optical design, the lens can express distortion smoothly, thereby producing stable images.
5. It compensates aberrations using a complex aspherical lens and, in the fully open position, produces high resolution and high contrast at the center of the lens as well as around the periphery of the lens.
6. The detachable petal type hood and UMC (Ultra Multi Coating) design suppresses flaring and ghost images.
7. Robust durability with a high strength aluminum body.
8. Smooth control when a follow focus is attached since the lens is equipped with a gear for the focus and aperture.

The 8mm T3.8 UMC FISH-EYE CS II for video recording is designed with its own mount. You can mount the lens directly onto the camera without using an adapter.

- ※ Please read this instruction manual carefully and use the product accordingly.
- ※ Please read the 'Safety Precautions' at the back of this instruction manual prior to use.

● Please read this instruction manual prior to use. ●

The diagram shows an exploded view of a microscope eyepiece assembly. The components are numbered as follows:

- 1: Mount (bottom base)
- 2: Distance scale point (central scale)
- 3: Hood Mount (upper housing)
- 4: Point ring (upper ring)
- 5: Aperture adjustment gear (lower ring)
- 6: Focusing gear (central gear)
- 7: Focus scaling ring (upper ring)
- 8: Focusing gear (lower gear)

2. Attaching and Detaching from the Camera

The 8mm T3.8 UMC FISH-EYE CS II lens mount is uniquely designed for Nikon, Sony α , Sony E, Canon, Four-Thirds, and Samsung NX cameras.

[Attaching]

Gently hold the lens hood, align the camera mount attachment point with the attachment reference point or line on the lens, push the lens into the camera and gently rotate the lens 90 degrees clockwise from the front view, until it makes a clicking sound.

[Detaching]

Gently hold the lens hood, press the lens release button on the camera, and turn the lens counterclockwise to detach the lens.

3. Focus Adjustment

When using the 8mm T3.8 UMC FISH-EYE CS II lens, you can set the focus of a subject by turning the focus adjustment gear, since it is an MF (Manual Focus) adjustment lens.

[Nikon Mount]

- ① To change the focus from a subject that is far away to a subject that is close, turn the focus gear counterclockwise (from ∞ to 0.3) and focus on the clearest subject by using the indicator signal on the camera or by checking visually.
- ② To change the focus from a subject that is close to a subject that is far away, turn the focus gear clockwise (from 0.3 to ∞) and focus on the clearest subject by using the indicator signal on the camera or by checking visually.

[Sony α / Sony E / Canon / Four Thirds / Samsung NX Mount]

- ① To change the focus from a subject that is far away to a subject that is close, turn the focusing gear clockwise (from ∞ to 0.3) and focus on the clearest subject by checking visually.
- ② To change the focus from a subject that is close to a subject that is far away, turn the focusing gear counterclockwise (from 0.3 to ∞) and focus on the clearest subject by checking visually.

4. Brightness Control

Turn the aperture adjustment gear to set the desired brightness for the 8mm T3.8 UMC FISH-EYE CS II lens.
You can set T NO from 3.8 to 22.
(The aperture is not positioned at any exact point, since it is adjustable continuously without steps.)

5. Mounting a Hood

The bayonet-type hood guarantees speedy, efficient, safe and precise installation and facilitates shooting that is free from ghosting or flaring.

[Figure]

Align the attachment reference point on the hood with the hood reference point on the lens, push the hood onto the lens and turn the hood clockwise until it makes a clicking sound.

6. Camera settings

Some cameras require special settings prior to using the lens.
Please refer to the following, and set the camera, if necessary.

○ Nikon

- 1) Record a video in M or A mode.
- 2) Adjust the exposure using the exposure compensation dial steps +5 to -5.

(The above procedure applies to the D7000. Settings for the camera or the menu may be different depending on the model or due to a menu upgrade, therefore refer to the camera manual or contact the camera manufacturer for more detailed information.)

○ Sony α

- 1) Record a video in A, S, P or M mode.

(The above procedure applies to the A580. Settings for the camera or the menu may be different depending on the model or due to a menu upgrade, therefore refer to the camera manual or contact the camera manufacturer for more detailed information.)

○ Sony E

- 1) Record a video in A, S, P or M mode.
- 2) Adjust the exposure by rotating the dial at the back of the camera.

(The above procedure applies to the NEX-5. Settings for the camera or the menu may be different depending on the model or due to a menu upgrade, therefore refer to the camera manual or contact the camera manufacturer for more detailed information.)

○ Canon

- 1) Record a video in Av, Tv, P, CA, □ or M mode.
- 2) Please note that while recording a video the shutter speed is limited to a minimum of 1/30.

(The above procedure applies to the 5D MARKII. Settings for the camera or the menu may be different depending on the model or due to a menu upgrade, therefore refer to the camera manual or contact the camera manufacturer for more detailed information.)

○ Samsung NX

- 1) Record a video in A, M, or $\frac{1}{250}$ mode.
- 2) Please note that while recording a video the shutter speed is limited to a minimum of 1/30.

(The above procedure applies to the NX 200. Settings for the camera or the menu may be different depending on the model or due to a menu upgrade, therefore refer to the camera manual or contact the camera manufacturer for more detailed information.)

○ Four-Thirds FT

- 1) Record a video in $\frac{1}{250}$ P, A, or M mode.
- 2) Please note that while recording a video the shutter speed is limited to a minimum of 1/30.

(The above procedure applies to the E-5. Settings for the camera or the menu may be different depending on the model or due to a menu upgrade, therefore refer to the camera manual or contact the camera manufacturer for more detailed information.)

7. SPEC							
SPECIFICATIONS	8mm 1:3.8 UMC FISH-EYE II (8MM FISH-EYE)						
APERTURE RANGE(STOP)	T3.8 to T22						
OPTICAL CONSTRUCTION	10 ELEMENT IN 7 GROUPS (1 ASPHERICAL LENS)						
MINIMUM FOCUSING DISTANCE	0.3m(1.0ft)						
FILTER SIZE	NONE						
FRONT DIAMETER	∅ 75.0mm						
MOUNT	NIKON SONY α CANON FOUR-THIRDS SONY E SAMSUNG NX						
ANGLE OF VIEW (DIAGONAL)	APS-C	180°	180°	167°	-	180°	180°
	4/3*	-	-	-	138.3°	-	-
LENGTH(LENS MOUNT TO FRONT)		72.6mm	74.9mm	75.1mm	80.4mm	103.5mm	93.8mm
WEIGHT(CAP MOUNT DETACHABLE)		430g	436g	455g	440g	465g	476g
GEAR	MODULE	0.8					
	A	7mm					
	B	4mm					
	C	34mm	34mm				
	D	8mm	10mm	10.5mm	15.8mm	36.5mm	29mm
	FOCUS DIAMETER	∅ 73.6mm	∅ 72.6mm				
APERTURE DIAMETER		∅ 70.4mm	∅ 72.2mm				

Symptom	Cause	Action
The lens cannot be attached to the camera.	The reference point on the lens is not aligned with the lens attachment reference point on the camera.	Align the reference point on the lens with the lens attachment reference point on the camera.
The lens cannot be detached from the camera.	Incorrect rotation direction for detaching the lens. If you turn the lens while holding the camera, it may cause damage to the lens.	Press the lens release button on the camera, and gently turn the lens to the lens attachment/detachment reference points. In the direction as marked on the camera, and then pull the lens forward.
Dark image.	Incorrect focusing, insufficient shutter speed, or camera shake.	Turn the focusing ring while checking the subject using the indicator in the corners or checking visually to set the focus until the subject is clear and centered, and then press the shutter. After selecting a shutter speed of 1/125 sec or faster, steady the camera and take a photograph.
Automatic focusing does not work properly.	This is a manual focusing lens and does not have an automatic function.	Turn the focusing ring to focus on a subject.
The pictures are too dark or too bright.	The exposure is incorrect.	Set the aperture adjustment ring for the lens and the camera shutter speed appropriately.
The edges of the picture get dark when using a manual camera or a digital camera with a 1:1 image sensor.	As this lens is optimized for APS-C size images, the edges of the picture look dark when using a digital camera for 1:1 sized images.	Use a camera with APS-C sized images.
The camera flash is not synchronized to the camera.	A manual control lens may not be compatible depending on the camera.	See the camera manual.
There is no camera focus indicator or display.	This lens does not have electronic contacts, so there is no communication with the camera.	This does not indicate that there is a problem with shooting.
Zoom failure.	This lens is a short focus lens.	
The lens cannot be mounted on other camera.	This lens is designed for a specific mount type.	Please buy the required camera to use this lens.
I want to attach my 2X or 1.4X converter lens.	Our converter is designed for the T (MZ) REMOTE mount only, thus it cannot be used with this product.	Use each company's own mount cover. However, be aware that auto focusing will not be available.

9. Safety Precautions

The following precautions are divided into two types according to the level of danger.

WARNING

If the instructions are not followed, it may cause death or serious injury to the users.

CAUTION

If the instructions are not followed, it may cause death or serious injury to the users.

⚠ WARNING

Don't look into the sun directly through the lens. It may cause blindness.

⚠ CAUTION

⚠ About the lens to be covered immediately after use: If you immediately clean the lens right after use, it may cause scratches or other damage. Therefore, please wait for a while before cleaning.

⚠ Don't attempt to modify or use the lens. If you modify or use the lens, it may lead to a fire or electric shock, or cause damage to the equipment.

The following programs are used in the below precautions:

- ① About whether the lens is in the program or not. (p. 16)
- ② About whether the lens is in the program or not. (p. 16)
- ③ About whether the lens is in the program or not. (p. 16)
- ④ About whether the lens is in the program or not. (p. 16)
- ⑤ About whether the lens is in the program or not. (p. 16)
- ⑥ About whether the lens is in the program or not. (p. 16)
- ⑦ About whether the lens is in the program or not. (p. 16)
- ⑧ About whether the lens is in the program or not. (p. 16)
- ⑨ About whether the lens is in the program or not. (p. 16)
- ⑩ About whether the lens is in the program or not. (p. 16)
- ⑪ About whether the lens is in the program or not. (p. 16)
- ⑫ About whether the lens is in the program or not. (p. 16)
- ⑬ About whether the lens is in the program or not. (p. 16)
- ⑭ About whether the lens is in the program or not. (p. 16)
- ⑮ About whether the lens is in the program or not. (p. 16)
- ⑯ About whether the lens is in the program or not. (p. 16)
- ⑰ About whether the lens is in the program or not. (p. 16)
- ⑱ About whether the lens is in the program or not. (p. 16)
- ⑲ About whether the lens is in the program or not. (p. 16)
- ⑳ About whether the lens is in the program or not. (p. 16)
- ㉑ About whether the lens is in the program or not. (p. 16)
- ㉒ About whether the lens is in the program or not. (p. 16)
- ㉓ About whether the lens is in the program or not. (p. 16)
- ㉔ About whether the lens is in the program or not. (p. 16)
- ㉕ About whether the lens is in the program or not. (p. 16)
- ㉖ About whether the lens is in the program or not. (p. 16)
- ㉗ About whether the lens is in the program or not. (p. 16)
- ㉘ About whether the lens is in the program or not. (p. 16)
- ㉙ About whether the lens is in the program or not. (p. 16)
- ㉚ About whether the lens is in the program or not. (p. 16)
- ㉛ About whether the lens is in the program or not. (p. 16)
- ㉜ About whether the lens is in the program or not. (p. 16)
- ㉝ About whether the lens is in the program or not. (p. 16)
- ㉞ About whether the lens is in the program or not. (p. 16)
- ㉟ About whether the lens is in the program or not. (p. 16)
- ㊱ About whether the lens is in the program or not. (p. 16)
- ㊲ About whether the lens is in the program or not. (p. 16)
- ㊳ About whether the lens is in the program or not. (p. 16)
- ㊴ About whether the lens is in the program or not. (p. 16)
- ㊵ About whether the lens is in the program or not. (p. 16)
- ㊶ About whether the lens is in the program or not. (p. 16)
- ㊷ About whether the lens is in the program or not. (p. 16)
- ㊸ About whether the lens is in the program or not. (p. 16)
- ㊹ About whether the lens is in the program or not. (p. 16)
- ㊺ About whether the lens is in the program or not. (p. 16)
- ㊻ About whether the lens is in the program or not. (p. 16)
- ㊼ About whether the lens is in the program or not. (p. 16)
- ㊽ About whether the lens is in the program or not. (p. 16)
- ㊾ About whether the lens is in the program or not. (p. 16)
- ㊿ About whether the lens is in the program or not. (p. 16)

⚠ Don't put excessive pressure on the lens. Excessive pressure may lead to the lens being damaged. Be sure to use the lens correctly.

⚠ Don't leave the lens in a place where it is exposed to strong light or a direct flame. It may lead to a fire or electric shock.

⚠ Please use the camera correctly. If you use the camera incorrectly, it may lead to a fire or electric shock. Please refer to the user manual for the correct usage.

⚠ Don't look at the sun directly through a camera lens. It may lead to a fire or electric shock. Please refer to the user manual for the correct usage.

WARNING!

Do not allow this product to get wet, or expose it to any electric or magnetic field. It may cause a fire or electric shock.

CAUTION!

- Do not use this product or store it close to devices that generate heat i.e., heaters, thermal regulators, stoves, stereo amplifiers.
- Do not expose the lens to drastic temperature changes.
- Do not touch the surface of the lens with your hand, or let it come into contact with other objects.
- Do not drop the lens.
- Do not soak the lens in water, and avoid water splashing onto the lens.
- If there are foreign bodies on the lens, use a lens cleaning kit only.

