

Roborock Qrevo Edge 2 Pro

Robotic Vacuum Cleaner User Manual

Read this user manual with diagrams carefully before using this product and store it properly for future reference.



Contents

- 003 Safety Information
- 004 International Symbols Explanation
- 004 RF Specification
- 005 Product Overview
- 006 Installation
- 007 Connecting to the App
- 007 Instructions for Use
- 009 Routine Maintenance
- 011 Basic Parameters
- 011 EU Declaration of Conformity
- 012 Common Issues

Safety Information

Restrictions

WARNING

- For the purposes of recharging the battery, only use the detachable docking station roborock EWFD64HRR provided with this product.
- The product must be switched off and the plug must be removed from socket outlet before cleaning or maintaining the product.
- In order to avoid a hazard due to inadvertent resetting of the thermal cut-out, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- The docking station can only be used to charge the robotic vacuum cleaner equipped with a 14.4 V/6400 mAh (TYP) lithium-ion battery.

CAUTION

- Only use the product in accordance with the User Manual. Any loss or damage caused by improper use will be borne by the user.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Make sure dustbin, washable filter, dust bag, side brush, mop cloths, main brushes and main brush cover are installed in place before cleaning.
- Do not use the product to clean hard or sharp objects (such as decoration wastes, glass, and nails) to avoid scratching the robot, the dock or the floor.
- Do not sit or stand on the robot or dock.
- To prevent corrosion or damage, do not use any disinfectant and only use cleaning solution recommended by Roborock.
- Do not put any low objects (such as shoes, mats) near raised areas like stairs. Otherwise, the robot may fall down caused by malfunctional sensors.
- To prevent water damage, make sure that the floor where the robot operates is free of water.
- Do not use this product on elevated surfaces without barriers such as the floor of a loft, an open-ended terrace, a slide, or top of furniture.
- Keep hair, loose clothing, fingers, and all body parts of people and pets away from seams, openings and moving parts of the product to avoid possible injury.
- Do not operate the product in a room where an infant or child is sleeping.
- Do not carry the robot using vertical bumper, magnetic top cover, side brush or bumper. Do not move the dock by lifting dock base, water tank handles or dust container cover.
- Do not use the dock to pick up stones, paper scraps, or other objects that may block the air duct.
- Do not use the robot or dock to vacuum any burning or smoking items such as cigarettes, matches, hot ashes, or any flammable or explosive items such as lighters, gasoline, or toner used in printers or copiers.
- Place the dock on a hard, flat floor. Keep the dock, robot, and power cord away from fire and heat sources like a heating radiator. Avoid humid and narrow spaces or locations where the robot may be suspended in the air.
- Do not place any object on top of the robot or dock, near the suction inlet of the dock, or cover them with any item (including dust-proof cover).

- Do not use without dust bag.
- Do not operate the product if it has been damaged in any way. Contact customer service for help.
- Always operate the device in well-ventilated areas to prevent overheating.
- Roborock and its retailers disclaim all liability for indirect, punitive, incidental, or consequential damages resulting from the use, misuse, or inability to use this product. This disclaimer does not affect any statutory rights that may not be disclaimed under applicable law.
- Do not rinse the robot and the dock.
- ⚠ – Caution, hot surface. Do not touch the clean water dispensers or drying air outlets.

Battery and Charging

WARNING

- Always use a properly grounded power outlet to minimize the risk of electric shock. If such a socket is not available, consult an electrician to make one available.
- Be sure that the supply voltage meets the requirements listed on the dock.
- To prevent potential smoke, heat, or fire, only use the battery, charger, power cord, dock, and other accessories provided with the product.
- Do not use the product with any type of power adapter, as this may cause danger and void the warranty.
- Do not discard waste batteries. Leave them with a professional recycling organization.
- If the dock is placed in an area susceptible to thunderstorms or with unstable voltage, take protection measures.
- If the product is left unused for a long period, store it in a cool, dry place after having it fully charged, unplugged, and switched off. Recharge it at least every three months to avoid battery overdischarge.
- To transport the product, be sure to unplug the dock, switch off the robot, and empty water tanks. In addition, drain and rinse the cleaning solution cartridge, leave it air dry completely, and then reinstall it. Use of the original packaging is advised.

International Symbols Explanation

⊕ – PROTECTIVE EARTH (Protective Ground) symbol

🏠 – For indoor use only.

RF Specification

Service	Protocol	Frequency Range	Max. Output Power
WiFi	802.11b/g/n	2400-2483.5 MHz	≤20dBm
Bluetooth	BLE 4.1	2400-2483.5 MHz	<10dBm

A Product Overview

A1 Robot (Top View)



Power/Clean

- Press and hold to turn the robot on or off
- Press to start cleaning

Power Indicator Light

- White: Battery level \geq 15%
- Red: Battery level $<$ 15%
- Breathing: Charging or starting up
- Flashing red: Error
- Breathing blue: Remote viewing
- Flashing blue slowly: Waiting for WiFi connection
- Flashing blue quickly: Connecting
- Steady blue: Voice assistant working/WiFi connected



Dock

- Robot not on dock: Press to start docking / Press and hold to start spot cleaning
- Robot on dock: Press to start emptying / Press and hold to wash the mop cloths

Note: Press any button to pause a running robot.

A1-1—Vertical Bumper

A1-2—LiDAR Sensor

A1-3—Microphones

A1-4—Upward Sensor

A1-5—Dock Locator

A1-6—Reactive AI Obstacle Recognition Sensor

A1-7—LED Fill Light

A1-8—Wall Sensor

A1-9—Speaker

A2 Robot (Bottom View)

A2-1—Cliff Sensors

A2-2—Carpet Sensor

A2-3—Side Brush

A2-4—Main Brush Cover

A2-5—Omnidirectional Wheel

A2-6—Main Brushes

A2-7—Main Brush Cover Latches

A2-8—Main Wheels

A2-9—Mop Cloths

A3 Robot (Top Cover Removed)

A3-1—Magnetic Top Cover

A3-2—Reset Button

A3-3—Bumper

A3-4—Suction Inlet

A3-5—Automatic Lift and Rotate Mop Modules

A3-6—Dustbin

A3-7—Charging Contacts

A3-8—Communication Sensor

A3-9—Self-Filling Port

A4 Mop Cloth Mount

A4-1—Hook and Loop Pads

A4-2—Mop Axle

Note: Secure the mop cloths flat in place.

A5 Mop Cloth

A6 Dustbin

A6-1—Dustbin Lid Latch

A6-2—Dustbin Lid

A6-3—Dustbin Latch

A6-4—Washable Filter

A6-5—Suction Inlet

A6-6—Air Inlet

A7 Dock Base

A8 Power Cord

A9 Disposable Dust Bag

A10 Empty Wash Fill Dock (Back View)

A10-1—Power Port

A10-2—Power Cord Slot

A10-3—Cord Outlets

A11 Empty Wash Fill Dock

A11-1—Water Tank Handle

A11-2—Dirty Water Tank

A11-3—Filter

A11-4—Cleaning Solution Cartridge

A11-5—Dock Base

A11-6—Clean Water Tank

A11-7—Water Tank Latch

A11-8—Status Indicator Light

- Breathing: Emptying/Mop washing
- Red: Dock error
- Off: Powered off/Charging

- A11-9—Dust Bag Slot
- A11-10—Dust Container Cover
- A11-11—Charging Contacts
- A11-12—Drain Port
- A11-13—Cleaning Tray Filter
- A11-14—Drying Air Outlets
- A11-15—Dock Location Beacon
- A11-16—Suction Inlet
- A11-17—Robot Refill Port
- A11-18—Cleaning Tray
- A11-19—Water Level Float
- A11-20—Clean Water Dispensers

Note: To minimize disturbance, the status indicator light will be off or dim in DND mode.

B Installation

B1 Important Information

- B1-1**—Tidy cords, hard or sharp objects (such as nails and glass), and loose items from the ground and move any unstable, fragile, precious, or dangerous items to prevent personal injury or property damage due to items becoming tangled in, struck by, or knocked over by the robot.
- B1-2**—When using the robot in a raised area (such as in a duplex apartment), always use a physical security barrier to prevent accidental falls that may result in personal injury or property damage.

Notes:

- When using the robot for the first time, follow it throughout its whole cleaning route and watch for potential problems. The robot will be able to clean by itself in future uses.
- To prevent excessive buildup of dirt on the mop cloths, floors should be vacuumed at least three times before the first mopping cycle.

B2 Assembly

B2-1—Attach the dock base by pressing down both sides of the base and the connecting part in the middle firmly until you hear a click.

Note: When moving the dock, secure the water tanks to prevent them from falling off.

B2-2—Connect the power cord to the back of the dock, and the power cord can exit at either the left or right cord slot opening.

B2-3—Align and install the mop axles into the robot in place until you hear a click.

B3 Positioning the Dock



Place the dock on a hard, flat floor (wood/tile/concrete etc.), flat against a wall, and reserve a space of at least 0.75 m (2.46 ft) in height, 0.4 m (1.31 ft) in width and 1.2 m (3.94 ft) in depth. Make sure that the location has good WiFi coverage for a better experience with the mobile app. Plug in and make sure that the status indicator light is on.

- B3-1**—More than 1.2 m (3.94 ft)
- B3-2**—More than 0.75 m (2.46 ft)
- B3-3**—More than 0.4 m (1.31 ft)

Notes:

- If the power cord hangs vertically to the ground, it may be caught by the robot, causing the dock to be moved or disconnected.
- The status indicator light is on when the dock is powered on, and off when the robot is charging.
- The status indicator light turns red if an error occurs.
- Place the dock on a hard, flat floor away from fire, heat, and water. Avoid narrow spaces or locations where the robot may be suspended in the air.
- Placing the dock on a soft surface (carpet/mat) may cause the dock to tilt and cause docking and departing problems.
- Keep the dock away from direct sunlight or anything that may block the dock location beacon, otherwise the robot may fail to return to the dock.
- Do not use the dock without clean water tank, dirty water tank, dust container cover, disposable dust bag, or cleaning tray.
- Maintain the dock according to the Routine Maintenance. Do not clean the dock power cord and charging contacts with a wet cloth or tissue.
- All docks are subject to water-based tests before leaving the factory. It is normal that a small amount of water remains in the waterway of the dock.

B4 Powering On & Charging

Press and hold  to power on the robot. Wait until the power indicator light is steady, and then place the robot in front of the dock. Make sure that the dock is plugged in. Then, press  and the robot will automatically return to the dock for charging. The robot is equipped with a built-in high-performance lithium-ion rechargeable battery pack. To maintain battery performance, keep the robot charged.

B4-1—Dock status indicator light off, robot power indicator light breathing:
Charging.

Note: The robot may not be turned on when the battery is low. In this case, place the robot on the dock for charging.

Connecting to the App

1. Download the App

Search for “Roborock” in the App Store or Google Play or scan the QR code to download and install the app.



2. Reset WiFi

Press and hold \odot and \square simultaneously until you hear the “Resetting WiFi” voice message. The reset is complete when the power indicator light flashes blue slowly. The robot will then wait for a connection.

Note: If you cannot connect to the robot due to your router configuration, a forgotten password, or any other reason, reset the WiFi and add your robot as a new device.

3. Add Device

Open the Roborock app, tap the “Add Device” or “+” button and add your device following the in-app guide.

Notes:

- The actual process may vary due to ongoing app updates. Follow the guide provided in the app.
- Only 2.4 GHz WiFi is supported.

C Instructions for Use

C1 Filling the Clean Water Tank

Lift the clean water tank, open its lid, and then fill it with tap water. After filling, close

the lid, lock the latch, and then put the clean water tank back to the dock.

Notes:

- To avoid deformation, only use cold water.
- If any water stains remain on the outside of the water tank, wipe them with a soft, dry cloth before reinstalling the tank.
- To prevent a high concentration of cleaning solution, add solution only to the cleaning solution cartridge.
- To prevent damage, do not use any disinfectant.

C2 Adding Cleaning Solution

1. Remove the dust container cover, pull out the entire cleaning solution cartridge by its bottom handle, and then place it on a hard, flat surface.

Note: To prevent the dust container cover from falling and hitting the robot, remove the cover with both hands, one on each side.

2. Open the lid of the cartridge and add cleaning solution.
3. Close the lid and put the cartridge back to the dock. Press the cartridge until you hear it lock with a click.
4. Install the dust container cover in place to make sure the dust container is securely sealed.

Notes:

- Make sure that the cleaning solution cartridge is entirely removed before adding cleaning solution.
- To prevent damage, do not use any disinfectant and only use cleaning solution recommended by Roborock in the solution cartridge.
- After adding, the robot will automatically add cleaning solution to the water for mop washing and robot water tank refilling according to the preset ratio to ensure optimal mopping performance.
- Cleaning solution is not included in the package. Purchase one if needed.

- If no floor cleaning solution is used daily, you may skip this step or disable Smart Cleaning Solution Filling in the app.

Turning On/Off

Press and hold \odot to turn on the robot. The power indicator light will come on, and the robot will wait for orders.

Press and hold \odot to turn off the robot and complete the cleaning cycle.

Note: The robot cannot be turned off when it is being charged.


Starting Cleaning

Press \odot to start cleaning. The robot will plan its cleaning route and in each room, it firstly draws out edges and then fills the room in a zigzag pattern. In so doing, the robot cleans all rooms one by one, thoroughly and efficiently.

Notes:



- To make sure the robot returns to the dock automatically, start the robot from the dock and do not move the dock during cleaning.
- Cleaning cannot start if the battery level is too low. Allow the robot to charge before starting a cleanup.
- Before cleaning, tidy cords (including the power cord of the dock) and valuables from the floor. Loose items may be dragged by the robot, resulting in the disconnection of electrical appliances or damage of cords and property.
- If cleaning is completed in less than 10 minutes, the robot will clean the area twice.
- If the battery runs low during a cleaning cycle, the robot will automatically return to the dock. After charging, the robot will resume where it left off.
- The robot will retract mop cloth mounts to clean the carpet. You can also set the carpet as a no-go zone in the app to avoid it.
- Before starting each cleaning task, make sure that the mop cloths have been properly installed.

Spot Cleaning

Press and hold  to start spot cleaning. Cleaning range: The robot cleans a 1.5 m (4.9 ft) × 1.5 m (4.9 ft) square area centered on itself.

Note: After spot cleaning, the robot will automatically return to the starting point and wait for orders.

Pause

When the robot is running, press any button to pause it, press  to resume cleaning. Press  on a paused robot to send it back to the dock.

Note: Placing a paused robot on the dock manually will end the current cleanup.

Sleep

If the robot is paused for over 10 minutes, it will go to sleep, and the power indicator light will flash every few seconds. Press any button to wake the robot up.

Notes:

- The robot will not go to sleep when it is charging.
- The robot will automatically shut down if left sleep for more than 12 hours.

DND Mode

The default Do Not Disturb (DND) period is from 22:00 to 08:00. You can use the app to disable the DND mode or modify the DND period, or set whether to enable auto top-up, emptying and drying, to dim indicator lights, or lower the volume of the voice message during the DND period.


Mop Washing

During cleaning, the robot automatically determines when it should return to the dock for mop washing and water tank refilling to maximize its mopping performance. To manually start washing, tap the corresponding button in the app. Press any button to stop washing.

Notes:

- Make sure the cleaning tray has been properly installed. Do not move the robot or the dock during mop washing.
- To avoid burns from hot water, do not touch the clean water dispensers.
- Mop wash frequency and mode can be modified in the app.

Emptying

After cleaning, the robot will return to the dock and auto-emptying will begin as needed. To manually start emptying, press  on the docked robot or tap the corresponding button in the app. Press any button to stop emptying.

Notes:

- When emptying has been left unused for a long period, empty the dustbin manually and make sure the air inlet is clear for optimal emptying performance.
- Auto-emptying can be disabled in the app.
- Avoid frequent manual emptying.
- Do not use without dust container cover or disposable dust bag installed in place.


Drying

After mop washing or after cleaning, drying will begin as needed. To manually start or stop drying, tap the corresponding button in the app.

Notes:

- Drying duration can be modified in the app.
- Auto-drying can be disabled in the app.
- Stay away from the drying air outlets during drying.

Charging

After cleaning, the robot will automatically return to the dock to charge. Press  to send the paused robot back to the dock. The power indicator light will breathe during robot charging.

Note: If the robot fails to find the dock, it will automatically return to its starting position. Place the robot on the dock manually to recharge.

Error

If an error occurs, the power indicator light will flash red or status indicator light will be steady red. A pop-up notification will appear in the app and a voice alert may sound.

Notes:

- The robot will go to sleep automatically if left in a malfunctioning state for over 10 minutes.
- Placing a malfunctioning robot on the dock manually will end the current cleanup.

Resetting the System


If the robot does not respond when a button is pressed or cannot be turned off, remove the magnetic top cover, open the rubber plug and press the Reset button inside to reset the system.

Note: After resetting the system, existing settings such as scheduled cleaning and WiFi will be restored to factory settings.

Deactivating WiFi

To disconnect the robot from WiFi, press the Reset button until you hear a voice message. Then wait for 5 minutes and the WiFi will be automatically deactivated. If you want to reconnect, please follow the related connecting instructions.

Restoring Factory Settings

If the robot does not function properly after a system reset, power it on. Press and hold  and at the same time, press the Reset button until you hear the "Restoring factory settings. This will take about 5 minutes." voice message. The robot will then be restored to factory settings.

Note: Open the rubber plug before pressing the Reset button.

D Routine Maintenance

Notes:

- The product must be switched off and the plug must be removed from socket outlet before cleaning or maintaining the product.
- The frequency of replacement may vary with the actual situation. If abnormal wear occurs, replace the parts immediately.

D1 Main Brushes

* Clean every 2 weeks and replace every 6-12 months.

D1-1—Main Brush Cover

D1-2—Main Brush Cover Latches

D1-3—Main Brushes

D1-4—Main Brush Bearing

D1-5—Protective Ring

D1-6—Turn over the robot and press the two latches inwards to remove the main brush cover.

D1-7—Lift the main brushes and pull them out, remove bearings and remove any entangled hair or dirt at both ends of the main brushes and bearings.

Note: If the protective rings get dirty, rotate and remove them for cleaning as needed.

D1-8—Reinstall the main brush bearings. And then, reinstall the main brushes and make sure the color of the main brush, main brush bearing and the arrow on the robot match.

D1-9—Reinstall the main brush cover. Make sure its four teeth are fully seated in the slots, and press the main brush cover until you hear it lock with a click.

Notes:

- It is recommended to wipe the main brushes with a wet cloth. If the main brushes are wet, air-dry them away from direct sunlight.
- Do not use corrosive cleaning fluid or disinfectant to clean the main brushes.

D2 Side Brush

* Clean monthly and replace every 3-6 months.

D2-1—Turn over the robot, unscrew the side brush, then remove and clean it.

D2-2—Align the central groove with the raised position on the robot, then tighten the screw to reinstall the side brush.

D3 Omnidirectional Wheel

* Clean as needed.

D3-1—Insert a tool, such as a small screwdriver, into the omnidirectional wheel from the left or the right to pry it out slowly.

Note: The omnidirectional wheel bracket cannot be removed.

D3-2—Rinse the wheel and the axle with water to remove any hair and dirt. Air-dry, reinstall, and press the wheel and axle back in place.

D4 Main Wheels

* Clean as needed.

Clean the main wheels with a soft, dry cloth.

D5 Dustbin

* Clean as needed.

D5-1—Remove the magnetic top cover of the robot and press the dustbin latch to take out the dustbin.

D5-2—Press the dustbin lid latch to open the dustbin lid and remove the washable filter, then empty the dustbin.

D5-3—Fill the dustbin with clean water, reinstall the washable filter and close the dustbin lid. Gently shake the dustbin, and then pour out the dirty water.

Note: To prevent blockage, only use clean water without any cleaning liquid.

D5-4—Allow at least 24 hours for the dustbin and washable filter to dry thoroughly before reinstalling them.

D6 Washable Filter

* Clean every 2 weeks and replace every 6-12 months.

D6-1—Press the dustbin lid latch to open the dustbin lid and remove the filter.

D6-2—Rinse the filter repeatedly and tap it to remove as much dirt as possible.

Note: Do not touch the surface of the filter with hands, brushes, or hard objects to avoid potential damage.

D6-3—Allow at least 24 hours for the filter to dry thoroughly before reinstalling it.

D7 Mop Cloths

* Clean as needed and replace every 1-3 months.

D7-1—Remove the mop cloths from mop cloth mounts. Clean the mop cloths and air-dry them.

Note: A dirty mop cloth will affect the mopping performance. Clean it before use.

D7-2—Stick the mop cloths on the mounts flat in place.

D8 Robot Sensors

* Clean as needed.

Use a soft, dry cloth to wipe and clean all sensors, including:

D8-1—Upward Sensor

D8-2—Dock Locator

D8-3—Reactive AI Obstacle Recognition Sensor

D8-4—Wall Sensor

D8-5—Communication Sensor

D8-6—Cliff Sensors

D8-7—Carpet Sensor

D9 Moving the Dock

To move the dock, grip the power cord slot on the back with one hand and the inner side of the front board with the other hand. Do not lift the dock base, water tank handles, or dust container cover directly to prevent the dock from falling off.

D10 Dirty Water Tank

* Clean as needed.

Open the dirty water tank lid and pour out the dirty water. Fill the tank with clean water, close the lid, lock the latch, and shake. Pour out the dirty water. Lock the lid and reinstall the tank.

Notes:

- To avoid deformation, only use cold water.
- If any water stains remain on the outside of the water tank, wipe them with a soft, dry cloth before reinstalling the tank.

D11 Charging Contacts

* Clean as needed.

Use a soft, dry cloth to wipe the charging contacts on the robot and the dock.

D12 Replacing Disposable Dust Bag

* Replace as needed.

D12-1—Remove the dust container cover.

Note: To prevent the dust container cover from falling and hitting the robot, remove the cover with both hands, one on each side.

D12-2—Remove the disposable dust bag and discard it.

Notes:

- The dust bag handle seals the bag on removal to prevent leakage.
- Always install a dust bag before putting back the dust container cover to avoid auto-emptying without the bag. You can also disable auto-emptying in the app.

D12-3—Clean the filter with a dry cloth, insert a new disposable dust bag into the slot all the way in, and spread it evenly.

Note: Make sure the disposable dust bag is properly installed to avoid waste escaping and damaging the dock.

D12-4—Reinstall the dust container cover in place to make sure the dust container is securely sealed.

D13 Cleaning Tray

* Clean as needed.

D13-1—Remove the cleaning tray.

D13-2—Rinse the cleaning tray and the filter with water.

D13-3—Reinstall the filter, then the cleaning tray.

Basic Parameters

Robot

Model	RREOVSP
Battery	14.4 V/6400 mAh (TYP) lithium-ion battery
Rated Input	20 VDC 1.5 A

Note: The serial number is on a sticker on the underside of the robot.

Empty Wash Fill Dock

Model	EWFD64HRR
Rated Input Voltage	220-240 VAC
Rated Frequency	50-60 Hz
Rated Input (Dust collection)	2.3 A
Rated Input (Hot-water mop washing)	5.7 A
Rated Input (Charging & drying)	0.58 A
Rated Output	20 VDC 1.5 A

EU Declaration of Conformity

Hereby, Beijing Roborock Technology Co., Ltd. declares that the radio equipment type RREOVSP is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: <https://global.roborock.com/pages/compliance>

Please visit the following link to view the network interfaces exposed by the product, services exposed through the network interfaces, and external sensors information.

<https://global.roborock.com/pages/compliance>

Common Issues

Issue	Solution
Unable to power on	<ul style="list-style-type: none">• Battery low. Put the robot on the dock and charge it before use.• Battery temperature too low or too high. Only use the robot within the range of 4-40°C (39-104°F).
Unable to charge	<ul style="list-style-type: none">• Dock not connected to power. Check whether both ends of the power cord are properly connected.• Poor contact. Clean the charging contacts of the dock and the robot.• Check that the status indicator light is on.
Slow charging	<ul style="list-style-type: none">• When used at high or low temperatures, the robot will automatically reduce its charging speed to extend battery life.• Charging contacts dirty. Wipe them with a soft, dry cloth.
Unable to return to dock	<ul style="list-style-type: none">• Too many obstacles near the dock. Clear them up or move the dock to an open area.• Robot too far from the dock. Place it closer and retry.
Abnormal behavior	<ul style="list-style-type: none">• Restart the robot.
Noise during cleaning	<ul style="list-style-type: none">• The main brushes, side brush, or main wheels may be jammed. Turn off the robot and clean them.• The omnidirectional wheel may be jammed. Use a screwdriver to remove it for cleaning.

Issue	Solution
Unable to connect to WiFi	<ul style="list-style-type: none">• WiFi disabled. Reset the WiFi and try again.• Poor WiFi signal. Move the robot to an area with better WiFi.• Abnormal WiFi connection. Reset the WiFi, download the latest app version and retry.• Unable to connect to WiFi abruptly. There may be an error with your router settings. Contact Roborock customer service for help with troubleshooting.
Is power always being drawn when the robot is on the dock?	<ul style="list-style-type: none">• The robot will draw power while it is docked to maintain battery performance, but the power consumption is extremely low.
Does the robot need to be charged for at least 16 hours for the first three uses?	<ul style="list-style-type: none">• No. Lithium-ion batteries have no memory effect. The robot can be used once fully charged.
The robot does not resume cleaning after recharging	<ul style="list-style-type: none">• Make sure that the robot is not in DND mode. DND mode will prevent auto top-up.• If the robot is placed manually on the dock or sent to dock by pressing buttons, it will not be able to resume cleaning.
The robot begins to miss certain spots	<ul style="list-style-type: none">• The wall sensor, cliff sensors, or carpet sensor may be dirty. Clean them with a soft, dry cloth.
Scheduled cleaning is not working	<ul style="list-style-type: none">• Keep the robot charged. Scheduled cleaning can only begin when the battery level is above 15%.

Issue	Solution
Poor cleaning performance and/or dust leakage	<ul style="list-style-type: none"> • The dustbin is full and needs emptying. • The filter is blocked and needs cleaning. • The main brushes are tangled up and need cleaning.
No or little water during mopping	<ul style="list-style-type: none"> • Use the mobile app to increase the water flow.
The robot cannot return to the charging dock after spot cleaning or when it has been moved manually	<ul style="list-style-type: none"> • After spot cleaning or a significant position change, the robot will re-generate the map. If the charging dock is too far away, it may not be able to return to recharge and must be placed on the charging dock manually.
The status indicator light is steady red	<ul style="list-style-type: none"> • Voltage error. Check that the local voltage meets the requirements listed on the dock. • Check clean water tank placement or refill the tank as required. • Check dirty water tank placement or empty the tank as required. • Check that the cleaning tray and cleaning tray filter have been correctly installed.
Reduced emptying performance or unusual noise when emptying	<ul style="list-style-type: none"> • The main brushes or main brush cover is not properly installed. Check and install in place. • The filter, air duct, suction inlet, air inlet, dustbin or disposable dust bag is blocked. Clean to remove blockages.
Reduced mop washing performance	<ul style="list-style-type: none"> • The mop cloths are not attached properly. Stick them on the mounts flat in place. • The floor is dirty. Change the mop washing mode to "Deep" in the app for better cleaning.

Issue	Solution
Unable to start auto-drying	<ul style="list-style-type: none"> • Auto-drying is disabled. Check in-app settings. • If the robot departs the dock during drying, the drying will end in advance. • In a humid environment, it is recommended to extend the drying duration in the app to improve the drying performance.
Unable to auto-empty	<ul style="list-style-type: none"> • Auto-emptying is disabled. Check in-app settings. • Dock dust container cover is not installed. Check and install. • Auto-emptying will not be triggered if the robot returns to the dock without cleaning. • The robot will not auto-empty after returning to the dock in DND mode. Adjust the cleaning time or DND period, or start emptying manually. • Auto-emptying will not be triggered if the robot is moved to the dock manually. Start emptying manually.
Unable to wash the mop cloths	<ul style="list-style-type: none"> • The mop cloths will not be washed if not used. • If the robot does not start from the dock or no dock is found on the app map, it will not return to the dock for mop washing. • Check clean water tank placement or refill the tank as required. • Check dirty water tank placement or empty the tank as required. • Check that the cleaning tray and cleaning tray filter have been correctly installed.

Issue	Solution
Unable to wash the mop cloths with hot water	<ul style="list-style-type: none"> • Check that Washing Water Temperature is set to Hot Water in the app.
The mop cloth is unable to extend	<ul style="list-style-type: none"> • Check that the FlexiArm Design Extended Mopping feature is enabled in the app. • The mop cloth will only extend along walls and certain obstacles. • Check if the mop extension structure is stuck.
The side brush is unable to extend	<ul style="list-style-type: none"> • Check that the FlexiArm Design Extended Cleaning feature is enabled in the app. • The side brush does not extend for every corner or every time when the robot cleans along the wall. • Check whether the side brush is jammed.
The LiDAR sensor is unable to raise/lower itself	<ul style="list-style-type: none"> • The LiDAR sensor lowers itself only when the robot cleans under furniture or appliances. • Check if any objects are stuck around the LiDAR sensor. • Wipe the upward sensor.
Unable to automatically detach/reinstall the mop cloth mounts	<ul style="list-style-type: none"> • Check that the Auto-Detach/Reinstall Mop Cloth Mounts feature is enabled in the app. • The Auto-Detach/Reinstall Mop Cloth Mounts feature is applicable only under specific conditions. • Check if the mop cloth mounts are jammed. • Check that the mop cloth mounts are placed in the position where they were removed. • Check that the mop cloth mounts are properly installed on the robot. • Check if any foreign objects are in the cleaning tray.

Importer:
Beryko s.r.o.
Pod Vinicemi 931/2, 301 00 Plzeň
www.beryko.cz

beryko

Robotic Vacuum Cleaner

Product Model: RREQVSP
Manufacturer: Beijing Roborock Technology Co., Ltd.
Address of Manufacturer: Room 1001, Floor 10, Building 3, Yard 17, Anju Road,
Changping District, Beijing, P.R. China

For more product information, visit our website: www.roborock.com
For after-sales support, email our after-sales service team:
Europe Support: support@roborock-eu.com

