



C3

USER MANUAL







Dear customer, thank you for purchasing our product. Please read the following instructions carefully and follow them to ensure that the product serves you safely and to your full satisfaction. This will prevent it from being misused or damaged. Avoid unprofessional handling of this device and always follow the principles of use of electrical appliances. Keep the operating instructions in a safe place.

Warnings

- Please read the user manual carefully before using the product.
- This product generates heat while working, please be cautious to avoid any possible harm.
- Please don't shine the product directly into eyes.
- Please keep the light away from children.
- Please use WUBEN or WUBEN recommended batteries.
- Please don't disassemble the light or it will not be covered by WUBEN warranty policy.
- Please don't throw the product or battery into fire.
- This is not a product intended for diving, please do not use it underwater.

Package List


Before using this product, please check whether the contents of the package are complete.

1. C3 × 1 	2. ABE 2600 rechargeable Li-ion battery × 1 
3. Type-C Charging Cable × 1 	4. Lanyard × 1 
5. Spare O-ring × 2 	6. Manual, Warranty Card, Quality Certificate × 1 

Product Operation


1. About Product

The WUBEN C3 is a rechargeable outdoor and household flashlight. It utilizes 1 × OSRAM P9 LED, powered by 1 × high drain 18650 Li-ion battery, with which the light can emit a maximum of 1200lm and can project as far as 179m away. The built-in Type-C charging design makes it more convenient to use.



2. Installation

Please remove the insulation plate before using.



3. Operation

1. ON/OFF: Press the button once to turn the light on/off.

2. Default Output Selection: When the light is on, press the switch once to cycle through Eco-Low-Med-High outputs. Press the button again to turn it off. The product has a memory function, and therefore it will remember the last output level used when being turned off.

3. Flash Mode:

- **Strobe:** When the light is on, press the tail switch twice to activate Strobe, press again to deactivate.
- **SOS:** When the light is on, press the tail switch three times to activate SOS, press again to deactivate.

4. Power Source (1 × 18650 battery, compatible with 2 × CR123A battery)

Battery Name	Description	Recommended	Cautious	Banned
18650	3.7V battery with protection circuit	√		
18650	3.7V battery without protection circuit		√	
CR123A	3V disposable battery		√	
RCR123A	3.7V rechargeable battery			√
16340	3.7V rechargeable battery			√
18350	3.7V rechargeable battery			√

5. Charging Status Indication

Please make sure the light is off before charging. Open the rubber cover, connect the flashlight to any 5V/2A charging device with a Type-C charging cable to charge it. It takes about 3h to fully charge the light (based on 5V/2A adapter). Please remove the charging cable in time after the charging is finished.

Charging	Red light on
Charging finished	Green light on












Only use batteries with protection circuits.

6. Battery Capacity (C) Status Indication

$C \geq 90\%$	Green light on (turns off after 5s)
$90\% > C \geq 40\%$	Green light flashing (turns off after 5s)
$40\% > C \geq 15\%$	Red light on (turns off after 5s)
$15\% > C > 0$	Red light flashing

Parameters

FL1 Standard	High	Med	Low	Eco	Strobe	SOS
	1200  500 LM	400LM	80LM	5LM	1200LM	200LM
	1+2.5 hours	3.5 hours	20 hours	143 hours	/	/
	179m				1.5m	
	7985cd				IP68 (2m underwater for 1h)	
	73g / 2.57oz (without battery) 123g / 4.34oz (with battery)					
	121.5mm × 25.4mm 4.78in × 1in (L × D)					

All data is derived from experiments of WUBEN lab according to the ANSI/NEMA FL1 standard, results may vary because of different experimental equipment, experimental environment or other factors. The experiments are based on ABE2600 rechargeable Li-ion battery .

Maintenance

- The O-Ring may be damaged after long time use. Please replace the O-Ring in time to ensure the waterproofness of the product.
- Please use WUBEN batteries or WUBEN recommended batteries.
- When the flashlight indicates low power, please charge or replace the battery in time to avoid affecting the durability of the battery.
- Please use alcohol and a rag to clean the conductive parts of the flashlight.
- When not in use for a long time, please remove the battery to prevent the battery from leaking or exploding. Store the flashlight in a dry and ventilated place.
- Never use concentrated or abrasive cleaners on the lamp housing.

FAQs

Problems	Causes	Solutions
Abnormal flash or failure to turn on	Check if the switch is turned on correctly.	Turn on the switch
	Check if the product is assembled correctly.	Tighten the assembly parts.
	Check if the battery is not reversed.	Remove the battery and reassemble the product correctly.
	Check the conductive position for dirt or any grime.	Clean the surface with alcohol.
	Check whether the battery is not low on power.	Use the charger to check and/or power the battery.
Abnormal noise	Check whether there isn't any foreign matter in the tube.	Pour out possible foreign matter.
	Damage to parts.	Contact your seller.

If your problems still aren't solved, please contact WUBEN headquarters for after-sales service.

Warranty Policy

A new product purchased in the Alza.cz sales network is warranted for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide proof of purchase with the original date of purchase.

The following are considered to be a conflict with the warranty conditions, for which the warranty claim may not be recognized:

- Use of the product for a purpose other than that for which the product is intended or failure to follow the instructions for maintenance, operation and service of the product.
- Damage to the product due to a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (eg during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, eg sunlight and other radiation or electromagnetic fields, ingress of fluid or object, mains overvoltage, voltage generated by electrostatic discharge (including lightning), faulty supply or input voltage and inappropriate polarity of this voltage, chemical processes, e.g. used power supplies, etc.
- If modifications, alterations, design changes, or alterations have been made by anyone to change or extend the product's features over the purchase or use of non-genuine components.
- Copies of proof of purchase of the product, altered, supplemented, without the original data or otherwise damaged documents on the purchase of the product will not be considered as documents proving the purchase of the claimed product.

EU DECLARATION OF CONFORMITY

Identification data of the manufacturer's / importer's authorized representative:

Importer: Alza.cz a.s.

Registered office: Jankovcova 1522/53, Holešovice, 170 00 Prague 7

IČO: 27082440

Subject of the declaration:

Title: Rechargeable LED flashlight

Model : C3

The above product has been tested in accordance with the standard (s) used for demonstration in accordance with the essential requirements laid down in the Directive (s):

Directive No. 2014/30 / EU

Directive No. 2011/65 / EU as amended by 2015/863 / EU

Prague, 7/23/2020



WEEE

This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE - 2012/19 / EU). Instead it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.



Manufacturer

SHENZHEN SHENGQI LIGHTING TECHNOLOGY CO., LTD.

E-mail: info@wubenlight.com

Web: www.wubenlight.com

Address: 202#, Building A, Jihe E-Business Park, No. 33 Yangmei Road, Bantian Street,
Longgang District, Shenzhen, China

Importer

Alza.cz a.s.

Jankovcova 1522/53, Holešovice

170 00 Praha 7

www.alza.cz