

T70

USER MANUAL




Dear customer, thank you for purchasing our product. Please read the following instructions carefully and follow them to ensure that the product serves you safely and to your full satisfaction. This will prevent it from being misused or damaged. Avoid unprofessional handling of this device and always follow the principles of use of electrical appliances. Keep the operating instructions in a safe place.

Warnings

- Please read the user manual carefully before using the product.
- This product generates heat while working, please be cautious to avoid any possible harm.
- Please don't shine the product directly into eyes.
- Please keep the light away from children.
- Please use WUBEN or WUBEN recommended batteries.
- Please don't disassemble the light or it will not be covered by WUBEN warranty policy.
- Please don't throw the product or battery into fire.
- This is not a product intended for diving, please do not use it underwater.

Package List


Before using this product, please check whether the contents of the package are complete.



Product Operation

1. About Product

The WUBEN T70 is a multifunctional flashlight for use in outdoors and camping activities. It utilizes 1 × CREE XHP70 LED, powered by 1 × high drain 26650 Li-ion battery with a 5000mAh capacity. The built-in Type-C charging design makes it more convenient to use.



2. Installation

Please remove the insulation plate before using.



3. Operation

1. ON/OFF: Press the button once to turn the light on/off.

2. Default Output Selection: When the light is on, press the switch once to cycle through Low-Med-High-Turbo outputs. Press and hold the switch for 2s to turn off the light.

3. Continuous Output Selections: When the light is on, press the switch three times to get into continuous output selection Start from Low to Turbo and then Turbo to Low, release to select the current output, and the click the switch three times again to switch into default output selection mode.

4. Flash Mode: When the light is not on continuous output brightness selection mode, press the switch twice to switch between Strobe and SOS modes, then click once to exit the flash mode.

5. Instant Turbo: Press the switch once to activate turbo output, then press again to turn it off.

4. Lock and Unlock

When the light is off, it blinks 3 times to indicate lockout status. Any operations on the switch will activate the blue light in the switch to indicate the lockout status, with the exception of three presses, which unlocks the light.

5. Battery Status Indication

Please make sure the light is off before charging. Connect a Type-C charging cable with the light and adapter of 5V / 2A to charge. It takes about 4h to fully charge the light (based on 5V / 2A adapter).

Power below 15%	Red light flashes
Power 15% ~ 40%	Red light on
Power 41% ~ 90%	Blue light flashing
Power 91% ~ 100%	Blue light on

A Only use batteries with protection circuits.

Make sure the rubber cap is covered well after the charging is finished to not compromise the IP68 waterproof level.

Power 100% ~ 80%	Blue light on (turns off after 5s)
Power 79% ~ 30%	Blue light flashing (turns off after 5s)
Power 29% ~ 15%	Red light on (turns off after 5s)
Power below 15%	Red light flashing

Parameters

FL1	Turbo	High	Med	Low	Strobe	SOS
Standard						
345	4200 Ղ	1300LM	400LM	40LM	4200LM	100LM
	1300 LM					
\bigcirc	1+120	3.5h	7.5h	35h	/	/
	mins					
V	250m			Ń	1m	
	15750cd			- Maril	IP68 (2m under	water for 1h)
∆ ⊺ ∆	177g / 6.24oz (without battery) 261g / 9.21oz (with battery)					
ليضاعلونها	139.7mm × 42mm 5.5in × 1.65in (L × D)					

All data is derived from experiments of WUBEN lab according to the ANSI/NEMA FL1 standard, results may vary because of different experimental equipment, experimental environment or other factors. The experiments are based on WUBEN 26650 Li-ion battery (5000mAh).

Accessory Recommendations

Holster, ABT500C battery, extended tube.

Maintenance

- The O-Ring may be damaged after long time use. Please replace the O-Ring in time to ensure the waterproofness of the product.
- Please use WUBEN batteries or WUBEN recommended batteries.
- When the flashlight indicates low power, please charge or replace the battery in time to avoid affecting the durability of the battery.
- Please use alcohol and a rag to clean the conductive parts of the flashlight.
- When not in use for a long time, please remove the battery to prevent the battery from leaking or exploding. Store the flashlight in a dry and ventilated place.
- Never use concentrated or abrasive cleaners on the lamp housing.

Problems	Causes	Solutions	
	Check whether the flashlight	Unlock the flashlight.	
Abnormal flash	isn't in lockout mode.		
or failure to	Check if the switch is turned on	Turn on the switch	
turn on	correcctly.		
	Check if the product is	Tighten the assembly parts.	
	assembled correctly.		
	Check if the battery is not	Remove the battery and	
	reversed.	reassemble the product correctly.	
	Check the conductive position	Clean the surface with alcohol.	
	for dirt or any grime.		
	Check whether the battery is	Us the charger to check and/or	
	not low on power.	power the battery.	
Abnormal	Check whether there isn't any	Pour out possible foreign matter.	
noise	foreign matter in the tube.		
	Damage to parts.	Contact your seller.	

FAQs

If your problems still aren't solved, please contact WUBEN headquarters for after-sales service.

Warranty Policy

A new product purchased in the Alza.cz sales network is warranted for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide proof of purchase with the original date of purchase.

The following are considered to be a conflict with the warranty conditions, for which the warranty claim may not be recognized:

- Use of the product for a purpose other than that for which the product is intended or failure to follow the instructions for maintenance, operation and service of the product.
- Damage to the product due to a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (eg during transport, cleaning by inappropriate means, etc.).
- Natural wear and aging of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, eg sunlight and other radiation or electromagnetic fields, ingress of fluid or object, mains overvoltage, voltage generated by electrostatic discharge (including lightning), faulty supply or input voltage and inappropriate polarity of this voltage, chemical processes, e.g. used power supplies, etc.
- If modifications, alterations, design changes, or alterations have been made by anyone to change or extend the product's features over the purchase or use of non-genuine components.
- Copies of proof of purchase of the product, altered, supplemented, without the original data or otherwise damaged documents on the purchase of the product will not be considered as documents proving the purchase of the claimed product.

EU DECLARATION OF CONFORMITY

Identification data of the manufacturer's / importer's authorized representative:

Importer: Alza.cz a.s. Registered office: Jankovcova 1522/53, Holešovice, 170 00 Prague 7 IČO: 27082440

Subject of the declaration: Title: Rechargeable LED flashlight Model : T70

The above product has been tested in accordance with the standard (s) used for demonstrationin accordance with the essential requirements laid down in the Directive (s):

Directive No. 2014/30 / EU Directive No. 2011/65 / EU as amended by 2015/863 / EU

Prague, 7/23/2020

CE

WEEE

This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE - 2012/19 / EU). Instead it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.



Manufacturer

SHENZHEN SHENGQI LIGHTING TECHNOLOGY CO., LTD. E-mail: info@wubenlight.com Web: www.wubenlight.com Address: 202#, Building A, Jihe E-Business Park, No. 33 Yangmei Road, Bantian Street, Longgang District, Shenzhen, China

Importer

Alza.cz a.s. Jankovcova 1522/53, Holešovice 170 00 Praha 7 www.alza.cz

All rights reserved. ©2020 alza.cz